








Machine	Explode	Code	Description
CB944-A Apuro Rice Cooker - 10Ltr	1	AC373	Lid Handle
CB944-A Apuro Rice Cooker - 10Ltr	2	AC374	Lid
CB944-A Apuro Rice Cooker - 10Ltr	3	AC375	Inner Bowl
CB944-A Apuro Rice Cooker - 10Ltr	4	AC381	Heat Sensor
CB944-A Apuro Rice Cooker - 10Ltr	5	AC380	Heating Plate
CB944-A Apuro Rice Cooker - 10Ltr	6	AC376	Sealed Plate
CB944-A Apuro Rice Cooker - 10Ltr	7	AK114	58°C Thermostat (old version)
CB944-A Apuro Rice Cooker - 10Ltr	7		Warm Heat Board (new version)
CB944-A Apuro Rice Cooker - 10Ltr	8	AC377	Body
CB944-A Apuro Rice Cooker - 10Ltr	9	AC378	Side Handle
CB944-A Apuro Rice Cooker - 10Ltr	10	AK115	Main Switch
CB944-A Apuro Rice Cooker - 10Ltr	11		Foot
CB944-A Apuro Rice Cooker - 10Ltr	12	AC383	Bottom Cover
CB944-A Apuro Rice Cooker - 10Ltr	13		Power Cord Clip
CB944-A Apuro Rice Cooker - 10Ltr	15	AC379	Electric Switch
CB944-A Apuro Rice Cooker - 10Ltr	16	AC384	Fuse
CB944-A Apuro Rice Cooker - 10Ltr	17		Ceramic Connector (2 Points)
CB944-A Apuro Rice Cooker - 10Ltr	18		Ceramic Connector (3 Points)
CB944-A Apuro Rice Cooker - 10Ltr	19	AG993	185°C Thermostat
CB944-A Apuro Rice Cooker - 10Ltr	20		Holder of 185°C Thermostat
CB944-A Apuro Rice Cooker - 10Ltr	N/A	AC643	Fork
CB944-A Apuro Rice Cooker - 10Ltr	N/A	AC644	Rice Paddle
CB944-A Apuro Rice Cooker - 10Ltr	N/A		Measuring Cup/450ml