







Machine	Explode	Code	Description
CJ753-A Apuro Salamander Grill	1		Body Frame
CJ753-A Apuro Salamander Grill	2		Thermal Insulation
CJ753-A Apuro Salamander Grill	3		Side Cover
CJ753-A Apuro Salamander Grill	4	AS024	Top Heatproof Tray
CJ753-A Apuro Salamander Grill	5	AS026	Crumb Tray
CJ753-A Apuro Salamander Grill	6		Bottom Baseboard
CJ753-A Apuro Salamander Grill	7		Heat Pipes Fixed Plate
CJ753-A Apuro Salamander Grill	8		AUS Power Cord
CJ753-A Apuro Salamander Grill	9	AL187	Power Cord Connector
CJ753-A Apuro Salamander Grill	10		Screw
CJ753-A Apuro Salamander Grill	11	AS016	Heating Element
CJ753-A Apuro Salamander Grill	12	AK025	Terminal Row
CJ753-A Apuro Salamander Grill	13	AS007	Indicator Light
CJ753-A Apuro Salamander Grill	14	AK014	Timer-old version
CJ753-A Apuro Salamander Grill	14	AS020	On/Off Switch-From CJ753-A-02
CJ753-A Apuro Salamander Grill	15	AK031	Thermostat
CJ753-A Apuro Salamander Grill	16	AS011	Knob Mandrel
CJ753-A Apuro Salamander Grill	17	AS009	Knob
CJ753-A Apuro Salamander Grill	18	AS028	Baking Net-old version
CJ753-A Apuro Salamander Grill	19	AS029	Baking Net Handle-old version
CJ753-A Apuro Salamander Grill	18	AS995	Baking Net for CJ753-A-02
CJ753-A Apuro Salamander Grill	19	AS996	Baking Net Handle for CJ753-A-02
CJ753-A Apuro Salamander Grill	20	AK017	Rubber Leg
CJ753-A Apuro Salamander Grill	21	AW196	Wall Bracket Right
CJ753-A Apuro Salamander Grill	22		Screw
CJ753-A Apuro Salamander Grill	23		Wall Bracket Left