




Machine	Explode	Code	Description
Apuro Bistro Single Contact Grill	1		Apron
Apuro Bistro Single Contact Grill	2		Top Cover Plate
Apuro Bistro Single Contact Grill	3		Rear Cover Plate
Apuro Bistro Single Contact Grill	4		Lower Heat Pipe Cover Plate
Apuro Bistro Single Contact Grill	5		Bottom Sealing Plate
Apuro Bistro Single Contact Grill	6	AU795	Oil Box
Apuro Bistro Single Contact Grill	7	AS322	Handle Assembly Right
Apuro Bistro Single Contact Grill	8	AS325	Thermostat
Apuro Bistro Single Contact Grill	9	AS328	Upper Heater
Apuro Bistro Single Contact Grill	10	AS329	Lower Heater
Apuro Bistro Single Contact Grill	11		Upper Griddle Plate (Ribbed) for CU600
Apuro Bistro Single Contact Grill	11		Upper Griddle Plate (Flat) for CU601
Apuro Bistro Single Contact Grill	12		Lower Griddle Plate (Ribbed) for CU600
Apuro Bistro Single Contact Grill	12		Lower Griddle Plate (Flat) for CU601
Apuro Bistro Single Contact Grill	13	AS332	Indicator Light
Apuro Bistro Single Contact Grill	14	AS333	Switch-old version
Apuro Bistro Single Contact Grill	14	AW124	Switch-new version
Apuro Bistro Single Contact Grill	15	AS334	Hi-Limit
Apuro Bistro Single Contact Grill	16	AW986	Protect Pipe
Apuro Bistro Single Contact Grill	17		Terminal
Apuro Bistro Single Contact Grill	18		AUS Power Cord
Apuro Bistro Single Contact Grill	19	AS337	Black Rubber Feet (set 4)
Apuro Bistro Single Contact Grill	20	AS344	Knob
Apuro Bistro Single Contact Grill	N/A	AW291	Allen Key