




Machine	Explode	Code	Description
Apuro Double Slice Conveyor Toaster	1	AS599	Speed Regulator
Apuro Double Slice Conveyor Toaster	2	AS332	Indicator Light
Apuro Double Slice Conveyor Toaster	3	AS344	Knob
Apuro Double Slice Conveyor Toaster	4		Knob Protection Box
Apuro Double Slice Conveyor Toaster	5	AS600	3 Gear Switch
Apuro Double Slice Conveyor Toaster	6	AW593	Crumb Tray
Apuro Double Slice Conveyor Toaster	7	AW643	Chain Net
Apuro Double Slice Conveyor Toaster	8	AW910	Wire Racks
Apuro Double Slice Conveyor Toaster	9		Terminal
Apuro Double Slice Conveyor Toaster	10	AS601	Lower Heater
Apuro Double Slice Conveyor Toaster	11	AS602	Upper Heater
Apuro Double Slice Conveyor Toaster	12	AW937	Front Chain Net Rod
Apuro Double Slice Conveyor Toaster	13		Rear Chain Net Rod
Apuro Double Slice Conveyor Toaster	14		Inner Top Cover
Apuro Double Slice Conveyor Toaster	15		Top Cover
Apuro Double Slice Conveyor Toaster	16		Rear Radiator Plate
Apuro Double Slice Conveyor Toaster	17		Hoarding
Apuro Double Slice Conveyor Toaster	20		Undercut Board
Apuro Double Slice Conveyor Toaster	21	AW938	Shaft Seat
Apuro Double Slice Conveyor Toaster	22	AW509	Shaft Gear
Apuro Double Slice Conveyor Toaster	23	AW455	Drive Chain
Apuro Double Slice Conveyor Toaster	24	AW510	Motor Gear
Apuro Double Slice Conveyor Toaster	25	AS603	Motor
Apuro Double Slice Conveyor Toaster	26	AW911	Feet (set 4)
Apuro Double Slice Conveyor Toaster	27		Furnace Body
Apuro Double Slice Conveyor Toaster	28		Bottom Sealing Plate
Apuro Double Slice Conveyor Toaster	29		AUS Power Cord
Apuro Double Slice Conveyor Toaster	30	AS604	Fan