




Machine	Explode	Code	Description
FU476-A Apuro Spice and Coffee Grinder	1	AS066	Cup Lid
FU476-A Apuro Spice and Coffee Grinder	2	AS067	Clear Cover
FU476-A Apuro Spice and Coffee Grinder	3	AS940	Upper Cover Seal Ring
FU476-A Apuro Spice and Coffee Grinder	4	AS941	Blade
FU476-A Apuro Spice and Coffee Grinder	5	AS942	φ8 Shaft Retaining Ring
FU476-A Apuro Spice and Coffee Grinder	6	AS071	Grinding Cup
FU476-A Apuro Spice and Coffee Grinder	7	AS072	Driven Wheel
FU476-A Apuro Spice and Coffee Grinder	8	AS073	Rubber Sheath
FU476-A Apuro Spice and Coffee Grinder	9	AS074	Switch Panel
FU476-A Apuro Spice and Coffee Grinder	10		Housing
FU476-A Apuro Spice and Coffee Grinder	11		Wire Cover
FU476-A Apuro Spice and Coffee Grinder	12	AS075	Button
FU476-A Apuro Spice and Coffee Grinder	13	AS076	Spring
FU476-A Apuro Spice and Coffee Grinder	14		Switch Box Cover
FU476-A Apuro Spice and Coffee Grinder	15	AS077	Switch Circuit Board
FU476-A Apuro Spice and Coffee Grinder	16		Switch Box Base
FU476-A Apuro Spice and Coffee Grinder	17	AS943	Five-tooth Drive Wheel
FU476-A Apuro Spice and Coffee Grinder	18		Touch Stand
FU476-A Apuro Spice and Coffee Grinder	19		Spring
FU476-A Apuro Spice and Coffee Grinder	20		Main Seat
FU476-A Apuro Spice and Coffee Grinder	21	AP335	Micro Switch
FU476-A Apuro Spice and Coffee Grinder	22		Micro Switch Seat
FU476-A Apuro Spice and Coffee Grinder	23		AUS Power Cord
FU476-A Apuro Spice and Coffee Grinder	24		Motor Bracket
FU476-A Apuro Spice and Coffee Grinder	25		Pressing Plate
FU476-A Apuro Spice and Coffee Grinder	26		Motor Shockproof Glue
FU476-A Apuro Spice and Coffee Grinder	27	AS079	Circuit Board
FU476-A Apuro Spice and Coffee Grinder	28		Motor
FU476-A Apuro Spice and Coffee Grinder	29		Rubber Hose
FU476-A Apuro Spice and Coffee Grinder	30		Base
FU476-A Apuro Spice and Coffee Grinder	31	AS080	Feet (set 4)
FU476-A Apuro Spice and Coffee Grinder	32	AS081	Brush
FU476-A Apuro Spice and Coffee Grinder	33	AS944	Grinding Cup Assembly