




Machine	Explode	Code	Description
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	1	AC144	S/S Lid
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	2	N289	S/S Inner Pot
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	3	AT193	S/S Top Collar for L715
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	3	AN773	S/S Top Collar for G107
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	4		S/S Cross
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	5	AP552	Internal Aluminium Container
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	6	AM182	Thermostat
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	7	AL990	Heating Element
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	8	AL991	Spring
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	9		S/S Painted Exterior for L715
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	9		S/S Painted Exterior for G107
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	10	N293	Magnetic Strip
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	11		AUS Power Cord
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	12	AN649	Plastic Strain Relief
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	13	AP196	Red Indicator Light
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	13	AL392	Green Indicator Light
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	15	AD618	EGO Switch
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	16	N111	Plastic Leg
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	17	AD619	Knob
Apuro Soup Kettle Black/Graphite Grey S 10Ltr	18		Bottom Cover With Screws