









# VOGUE

**Dishwasher Outlet Table**  
Assembly instructions



**Model:**  
**CM520/CM521**

	<b>X 1</b>		<b>X 2</b>
	<b>X 4</b>		<b>X 18</b>
	<b>X 2</b>		<b>X 1</b>
	<b>X 2</b>		<b>X 4</b>



**Fig 1**




**Fig 2**




**Fig 3**



**Fig 4**



**Fig 5**



**Fig 6**



**Fig 7**

## Safety Tips

- Position on a flat, stable surface.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- Whilst all care has been taken to remove sharp edges, care must be taken when cleaning or handling the sink to prevent risk of injury from exposed metal edges.

## Assembly

1. Remove all protective film from the legs and underneath the table, taking care to avoid scratching the surfaces.
2. Connect 2 straight tube clamps to long bar. [Fig 1]
3. Connect 1 straight tube clamp and 1 right tube clamp to each of the short tubes. [Fig 2&3]
4. Connect the 2 short tubes to the 1 long tube using the right tube clamps. [Fig 3]
5. Insert the 4 legs into the tube clamps, lining them up with the marks on the legs. [Fig 5]
6. Position the long tube of Fig 1 over the legs at front direction, lining it up with the same level of sink bottom. [Fig 6]
7. Using the grub screws to loosely secure the tubes to each leg.

**Note: Leaving the grub screws loose allows for adjustments to be made to the supporting tubes.**

8. Put the dishwasher-inlet table onto the legs using the sockets at each corner of the underside of the top. [Fig 7]
9. Adjust the tubes and legs so that they are level (use a spirit level if required).
10. Tighten all the grub screws
11. If necessary adjust the feet to level the table.
12. It is recommended that the table is attached to the wall, with suitable fixings, using the mounting lugs behind the upstand.

## Cleaning, Care & Maintenance

- Before using for the first time the sink should be cleaned thoroughly.
- Clean the table regularly using a cleaning agent suitable for use with stainless steel.
- Always remove cleaning agent residue. This can discolour the surface of the sink.
- Never leave the surfaces damp as this can cause discolouration.

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of VOGUE.

Every effort is made to ensure all details are correct at the time of going to press, however, VOGUE reserve the right to change specifications without notice.

AU	1300 225 960	15 Badgally Road, Campbelltown, 2560, NSW, Australia
----	--------------	---