



XPress Multipurpose Cooktop WSC300CE, CK

Unit Information

Crêpe making, simplified and perfected. The XPress™ cooks both sides simultaneously to produce flawlessly formed crêpes, minimizing prep time and maximizing output. Designed to also warm and cook tortillas, make quesadillas, and more, this dual-surface cooktop with digital controls is ideal for today's busy foodservice operations.




Illustration #	Part #	Description
1	038886	Rocker Switch
2	038877	Handle Insulation
3	038878	Handle Bracket
4	029993	Spring Washer (2 required Per unit)
5	038879	Screw (2 required Per unit)
6	038880	Top Handle Cover
7	038881	Bottom Handle Cover
8	037970	Screw (5 required Per unit)
9	038882	Hole Plug (5 required Per unit)
10	038883	Shield
11	038884	Timer Cover
12	038890	Power Board with heat sink
13	032359	Screw (6 required Per unit)
14a	037933	Europe Cord (Plug type "F")
14b	038894	United Kingdom Cord (Plug type "G")
15	032361	Strain Relief
16a	012409	Small Crimp Connector (4 required Per unit)
16b	019123	Large Crimp Connector (2 required Per unit)
17	013731	Cable Ties (8 required Per unit)
18	038887	17.75" Blue Lead
19	038888	19.75" Blue Lead
20	038889	20.25" Red Lead
21	038891	Bottom Plate
22	032353	Foot (4 required Per unit)
23	032354	Washer (4 required Per unit)
24	032355	Screw (4 required Per unit)
25	032750	Screw (6 required Per unit)
26	038874	Spreader
27	038133	Thermostat

Illustration #	Part #	Description
28	037504	Spring Washer (2 required Per unit)
29	032359	Screw (2 required Per unit)

