




Machine	Explode	Code	Description
HOST0505BR - HOST Bain Marie with Pots	1		Water Pan
HOST0505BR - HOST Bain Marie with Pots	2		Frame
HOST0505BR - HOST Bain Marie with Pots	3	AL194	Indicator Light
HOST0505BR - HOST Bain Marie with Pots	4	N146	On/Off Switch
HOST0505BR - HOST Bain Marie with Pots	5	AC885	LH Temperature Thermostat
HOST0505BR - HOST Bain Marie with Pots	6		Chrome Knob
HOST0505BR - HOST Bain Marie with Pots	10		Small Alu Plate
HOST0505BR - HOST Bain Marie with Pots	11	AL197	Auto Recover Thermostat
HOST0505BR - HOST Bain Marie with Pots	12		Pressure Plate for Thermostat Sensor
HOST0505BR - HOST Bain Marie with Pots	13		Main Screw
HOST0505BR - HOST Bain Marie with Pots	14		Bottom Plate
HOST0505BR - HOST Bain Marie with Pots	15	AC883	Rubber Feet
HOST0505BR - HOST Bain Marie with Pots	16		Cover for Heating Element
HOST0505BR - HOST Bain Marie with Pots	17		Pressure Sticker
HOST0505BR - HOST Bain Marie with Pots	18	AL198	Heating Element 1200W
HOST0505BR - HOST Bain Marie with Pots	19		Pressure Plate
HOST0505BR - HOST Bain Marie with Pots	20	AL199	Manual Thermostat
HOST0505BR - HOST Bain Marie with Pots	21		Alu. Plate
HOST0505BR - HOST Bain Marie with Pots	22	AC882	Strain Relief Bushing
HOST0505BR - HOST Bain Marie with Pots	23	AL917	Power Cord
HOST0505BR - HOST Bain Marie with Pots	24	CD546	Pot Holder/Top Panel
HOST0505BR - HOST Bain Marie with Pots	25	CD544	Round Pot
HOST0505BR - HOST Bain Marie with Pots	26	CD545	Lid