




Machine	Explode	Code	Description
HOST Pasta Cooker - 8Ltr 2.9kW	1		Skirt Panel
HOST Pasta Cooker - 8Ltr 2.9kW	2		Skirt Back Panel
HOST Pasta Cooker - 8Ltr 2.9kW	3		Foot Plate
HOST Pasta Cooker - 8Ltr 2.9kW	4		Black Rubber Feet (set 4)
HOST Pasta Cooker - 8Ltr 2.9kW	5		Tank
HOST Pasta Cooker - 8Ltr 2.9kW	6		Drain Tube
HOST Pasta Cooker - 8Ltr 2.9kW	7		Drain Valve
HOST Pasta Cooker - 8Ltr 2.9kW	8		Left & Right Support of Control Box
HOST Pasta Cooker - 8Ltr 2.9kW	9		Left & Right Side Panel of Control Box
HOST Pasta Cooker - 8Ltr 2.9kW	10		Skirt Panel of Control Box
HOST Pasta Cooker - 8Ltr 2.9kW	11		Back Panel of Control Box
HOST Pasta Cooker - 8Ltr 2.9kW	12		Heater
HOST Pasta Cooker - 8Ltr 2.9kW	13		Basket Holder
HOST Pasta Cooker - 8Ltr 2.9kW	14		Switch
HOST Pasta Cooker - 8Ltr 2.9kW	15		Thermostat With Knob
HOST Pasta Cooker - 8Ltr 2.9kW	16		Indicator Light
HOST Pasta Cooker - 8Ltr 2.9kW	17		Strengthen Panel of Control Box
HOST Pasta Cooker - 8Ltr 2.9kW	18		Net
HOST Pasta Cooker - 8Ltr 2.9kW	19		Handle
HOST Pasta Cooker - 8Ltr 2.9kW	20		Tank Lid
HOST Pasta Cooker - 8Ltr 2.9kW	21		Hi-Limit
HOST Pasta Cooker - 8Ltr 2.9kW	22		Circuit Board
HOST Pasta Cooker - 8Ltr 2.9kW	23		Basket