




Machine	Explode	Code	Description
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	1		Box
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	2	AK018	Upper Cover
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	7		Handle of Lid - AJ261
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	3		Sediment Stencil
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	4	AK019	Oil Pan
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	5	AK020	Basket
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	6		Basket Handle
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	8	AL056	220°C Thermal Cut Out
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	11		190°C Thermostat
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	9	AK022	Indicator Lights (Green & Red)
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	10	AJ263	On/Off Switch
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	12		Knob
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	13	AK024	Micro Switch
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	14		Control Box Rear Cover
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	15		UK Power Cord
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	16	AL187	Cable Connector
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	17	AK025	Terminal Block
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	18	AN950	Control Box
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	19		Hanging Rod
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	20		Oil Scale
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	21		Fixed Piece
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	22	AK026	Heating Element
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	23		Probe Clip Welding
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	24		Probe Clip
HOST0565FS - HOST Electric Fryer - 5Ltr 3kW	25	AK017	Rubber Feet (set 4)