




Machine	Explode	Code	Description
HOST Electric Fryer Single - 3kW 5Ltr	1		Apron
HOST Electric Fryer Single - 3kW 5Ltr	2		Apron Back Plate
HOST Electric Fryer Single - 3kW 5Ltr	3		Black Rubber Feet (set 4)
HOST Electric Fryer Single - 3kW 5Ltr	4		Foot Plate
HOST Electric Fryer Single - 3kW 5Ltr	5		Fretting Switch Roof
HOST Electric Fryer Single - 3kW 5Ltr	6		Dowel
HOST Electric Fryer Single - 3kW 5Ltr	7		Electric Box Hoarding
HOST Electric Fryer Single - 3kW 5Ltr	8		Side Panel for Electric Box
HOST Electric Fryer Single - 3kW 5Ltr	9		Side Panel
HOST Electric Fryer Single - 3kW 5Ltr	10		Electric Box Sealing Plate
HOST Electric Fryer Single - 3kW 5Ltr	11		Electric Heating Pipe
HOST Electric Fryer Single - 3kW 5Ltr	12		Travel Switch
HOST Electric Fryer Single - 3kW 5Ltr	13		Heater Protective Plate
HOST Electric Fryer Single - 3kW 5Ltr	14		Cover
HOST Electric Fryer Single - 3kW 5Ltr	15		Switch
HOST Electric Fryer Single - 3kW 5Ltr	16		Indicator Light
HOST Electric Fryer Single - 3kW 5Ltr	17		Knob
HOST Electric Fryer Single - 3kW 5Ltr	18		Handle
HOST Electric Fryer Single - 3kW 5Ltr	19		Rubber Sleeve
HOST Electric Fryer Single - 3kW 5Ltr	20		Blasting Net Support Piece
HOST Electric Fryer Single - 3kW 5Ltr	21		1/2 GN Pan
HOST Electric Fryer Single - 3kW 5Ltr	22		Temperature Limiter
HOST Electric Fryer Single - 3kW 5Ltr	23		EGO Thermostat
HOST Electric Fryer Single - 3kW 5Ltr	24		Basket