




Machine	Explode	Code	Description
HOST Countertop Griddle - Steel plate	1		Main Body
HOST Countertop Griddle - Steel plate	2		Control Box
HOST Countertop Griddle - Steel plate	3	AK034	Drip Tray
HOST Countertop Griddle - Steel plate	4		Drip Tray Fixing Plate
HOST Countertop Griddle - Steel plate	5		Control Box Plate
HOST Countertop Griddle - Steel plate	6		Heating Element Fixing Plate
HOST Countertop Griddle - Steel plate	7		Probe Clip
HOST Countertop Griddle - Steel plate	8		Insulation Plate 2
HOST Countertop Griddle - Steel plate	9		Insulation Plate 1
HOST Countertop Griddle - Steel plate	10		Base Plate
HOST Countertop Griddle - Steel plate	11	AK033	320°C Thermal Cut Out
HOST Countertop Griddle - Steel plate	12		UK Power Cord
HOST Countertop Griddle - Steel plate	13	AL187	Cable Connector
HOST Countertop Griddle - Steel plate	14	AK022	Indicator Lights (Green & Red)
HOST Countertop Griddle - Steel plate	15	AK031	300°C Thermostat
HOST Countertop Griddle - Steel plate	16		Knob
HOST Countertop Griddle - Steel plate	17	AK035	Heating Element
HOST Countertop Griddle - Steel plate	18	AK036	Terminal Block
HOST Countertop Griddle - Steel plate	19		Heat Insulation Cotton
HOST Countertop Griddle - Steel plate	20	AK017	Rubber Feet (set 4)