




Machine	Explode	Code	Description
HOST0595SG - HOST Quartz Salamander Grill	1		Body Frame
HOST0595SG - HOST Quartz Salamander Grill	2		Thermal Insulation
HOST0595SG - HOST Quartz Salamander Grill	3		Side Cover
HOST0595SG - HOST Quartz Salamander Grill	4		Top Heatproof Tray
HOST0595SG - HOST Quartz Salamander Grill	5		Crumb Tray
HOST0595SG - HOST Quartz Salamander Grill	6		Bottom Baseboard
HOST0595SG - HOST Quartz Salamander Grill	7		Heat Pipes Fixed Plate
HOST0595SG - HOST Quartz Salamander Grill	8		Power Cord
HOST0595SG - HOST Quartz Salamander Grill	9	AL187	The Power Cord Connector
HOST0595SG - HOST Quartz Salamander Grill	10		Screw+Nut
HOST0595SG - HOST Quartz Salamander Grill	11		Quartz Tube
HOST0595SG - HOST Quartz Salamander Grill	12	AK025	Terminal Row
HOST0595SG - HOST Quartz Salamander Grill	13	AJ264	Indicator Light
HOST0595SG - HOST Quartz Salamander Grill	14	AK014	Timer
HOST0595SG - HOST Quartz Salamander Grill	15	AK015	Position Selector
HOST0595SG - HOST Quartz Salamander Grill	16		Knob Mandrel
HOST0595SG - HOST Quartz Salamander Grill	17		Knob
HOST0595SG - HOST Quartz Salamander Grill	18		Baking Net
HOST0595SG - HOST Quartz Salamander Grill	19		Baking Net Handle
HOST0595SG - HOST Quartz Salamander Grill	20	AK017	Rubber Leg
HOST0595SG - HOST Quartz Salamander Grill	21		PVC Decal