




Machine	Explode	Code	Description
HOST Large Heated Banquet Cabinet	1	AJ073	Standard Castors
HOST Large Heated Banquet Cabinet	4		Braked Castors
HOST Large Heated Banquet Cabinet	2		Anti-collision Bumper Strip
HOST Large Heated Banquet Cabinet	3		Cabinet Body
HOST Large Heated Banquet Cabinet	5	AJ074	Drip Tray
HOST Large Heated Banquet Cabinet	6	AJ075	Door Seal
HOST Large Heated Banquet Cabinet	7	AK714	Lower Door Hinge
HOST Large Heated Banquet Cabinet	8		Door
HOST Large Heated Banquet Cabinet	9	AJ076	Lock & Key
HOST Large Heated Banquet Cabinet	10		Support Right
HOST Large Heated Banquet Cabinet	11		Support Left
HOST Large Heated Banquet Cabinet	12	AL225	Guide Right
HOST Large Heated Banquet Cabinet	13		Guide Left
HOST Large Heated Banquet Cabinet	14		Strip Against Door
HOST Large Heated Banquet Cabinet	15		Front Panel
HOST Large Heated Banquet Cabinet	16-17	AJ077	Controller (RK323A)
HOST Large Heated Banquet Cabinet	18		Fan Support
HOST Large Heated Banquet Cabinet	19	AJ202	Axial Flow Fan
HOST Large Heated Banquet Cabinet	20	AJ079	Heating Element
HOST Large Heated Banquet Cabinet	21	AJ078	Fan Motor & Blade
HOST Large Heated Banquet Cabinet	22		Support
HOST Large Heated Banquet Cabinet	23		Heating Element Support
HOST Large Heated Banquet Cabinet	24		Top Panel
HOST Large Heated Banquet Cabinet	25		Air Flow Conduct Board
HOST Large Heated Banquet Cabinet	26	AJ080	Upper Door Hinge
HOST Large Heated Banquet Cabinet	N/A	AN706	UK Power Cord
HOST Large Heated Banquet Cabinet	N/A	AM202	Kettle Style Socket for Mains Cable
HOST Large Heated Banquet Cabinet	N/A		Display Screen