




Machine	Explode	Code	Description
HOST Floor Standing Wine Fridge - 28 Bottle	1		Body
HOST Floor Standing Wine Fridge - 28 Bottle	2	AL008	Upper Hinge
HOST Floor Standing Wine Fridge - 28 Bottle	3		Upper Hinge Cover
HOST Floor Standing Wine Fridge - 28 Bottle	4		Light Cover
HOST Floor Standing Wine Fridge - 28 Bottle	5	AL010	LED Light
HOST Floor Standing Wine Fridge - 28 Bottle	6	AL011	Evaporator
HOST Floor Standing Wine Fridge - 28 Bottle	7	AL013	Wavy Shelf
HOST Floor Standing Wine Fridge - 28 Bottle	8		Upper Extrusion Strip Outer Cover
HOST Floor Standing Wine Fridge - 28 Bottle	9	AL031	Control Panel PCB
HOST Floor Standing Wine Fridge - 28 Bottle	10		Door
HOST Floor Standing Wine Fridge - 28 Bottle	11		Handle
HOST Floor Standing Wine Fridge - 28 Bottle	12	AL019	Door Seal
HOST Floor Standing Wine Fridge - 28 Bottle	13	AL021	Wine Rack
HOST Floor Standing Wine Fridge - 28 Bottle	14	AL014	Flat Shelf
HOST Floor Standing Wine Fridge - 28 Bottle	15	AL022	Lower Hinge
HOST Floor Standing Wine Fridge - 28 Bottle	16		Bottom Hinge Feet
HOST Floor Standing Wine Fridge - 28 Bottle	17	AL024	Adjustable Feet 17mm
HOST Floor Standing Wine Fridge - 28 Bottle	18		Adjustable Feet 14mm
HOST Floor Standing Wine Fridge - 28 Bottle	19		Compressor Base
HOST Floor Standing Wine Fridge - 28 Bottle	20		Plug
HOST Floor Standing Wine Fridge - 28 Bottle	21		Clamp Assembly
HOST Floor Standing Wine Fridge - 28 Bottle	22	AL025	Compressor (R600a)
HOST Floor Standing Wine Fridge - 28 Bottle	23	AL028	Water Tray
HOST Floor Standing Wine Fridge - 28 Bottle	24		Power Box
HOST Floor Standing Wine Fridge - 28 Bottle	25	AL030	PCB