




Machine	Explode	Code	Description
GP450 - Buffalo Convection Oven 4 x GN 1/1	1	AX028	Door Handle
GP450 - Buffalo Convection Oven 4 x GN 1/1	2		Outside Glass
GP450 - Buffalo Convection Oven 4 x GN 1/1	3		Inside Glass
GP450 - Buffalo Convection Oven 4 x GN 1/1	4	AX029	Door Seal
GP450 - Buffalo Convection Oven 4 x GN 1/1	5	AX031	Pan
GP450 - Buffalo Convection Oven 4 x GN 1/1	6	AX033	Shelf
GP450 - Buffalo Convection Oven 4 x GN 1/1	7		Motor Cover Plate
GP450 - Buffalo Convection Oven 4 x GN 1/1	8	AX035	Motor Fan Blade
GP450 - Buffalo Convection Oven 4 x GN 1/1	11		Motor
GP450 - Buffalo Convection Oven 4 x GN 1/1	9	AX036	Convection Heating Element
GP450 - Buffalo Convection Oven 4 x GN 1/1	10	AX038	Exhaust Pipe
GP450 - Buffalo Convection Oven 4 x GN 1/1	12	AU905	UK Power Cord
GP450 - Buffalo Convection Oven 4 x GN 1/1	13	AX040	Temperature Limiter
GP450 - Buffalo Convection Oven 4 x GN 1/1	14	AU903	Light
GP450 - Buffalo Convection Oven 4 x GN 1/1	15	AX041	AC Contactor
GP450 - Buffalo Convection Oven 4 x GN 1/1	16	AX042	Terminal
GP450 - Buffalo Convection Oven 4 x GN 1/1	17	AX043	Control Board
GP450 - Buffalo Convection Oven 4 x GN 1/1	18	AX044	Feet (set 4)
GP450 - Buffalo Convection Oven 4 x GN 1/1	19	AU906	Micro Switch
GP450 - Buffalo Convection Oven 4 x GN 1/1	20	AX045	Thermostat
GP450 - Buffalo Convection Oven 4 x GN 1/1	21	AX046	Light Switch
GP450 - Buffalo Convection Oven 4 x GN 1/1	22	AX047	Knob
GP450 - Buffalo Convection Oven 4 x GN 1/1	23	AX048	Timer