



















Machine	Explode	Code	Description
HOST Extra Large Contact Grill	1		Apron
HOST Extra Large Contact Grill	2		Top Cover Plate
HOST Extra Large Contact Grill	3		Rear Cover Plate
HOST Extra Large Contact Grill	4		Lower Heat Pipe Cover Plate
HOST Extra Large Contact Grill	5		Bottom Sealing Plate
HOST Extra Large Contact Grill	6	AU132	Oil Box
HOST Extra Large Contact Grill	7		Handle
HOST Extra Large Contact Grill	8	AS326	Thermostat
HOST Extra Large Contact Grill	9		Upper Heater
HOST Extra Large Contact Grill	10		Lower Heater
HOST Extra Large Contact Grill	11		Top Griddle (Ribbed) for HOST0551RR
HOST Extra Large Contact Grill	11		Top Griddle (Flat) for HOST0552FF
HOST Extra Large Contact Grill	12		Bottom Griddle (Ribbed) for HOST0551RR
HOST Extra Large Contact Grill	12		Bottom Griddle (Flat) for HOST0552FF
HOST Extra Large Contact Grill	13		Indicator Light
HOST Extra Large Contact Grill	14	AT580	Switch-old version
HOST Extra Large Contact Grill	14		Switch-new version
HOST Extra Large Contact Grill	15	AS334	Hi-Limit
HOST Extra Large Contact Grill	16		Guard Pipe
HOST Extra Large Contact Grill	17		Terminal
HOST Extra Large Contact Grill	18		UK Power Cord
HOST Extra Large Contact Grill	19	AS337	Black Rubber Feet (set 4)
HOST Extra Large Contact Grill	20		Knob
HOST Extra Large Contact Grill	N/A	AW291	Allen Key