



Machine	Explode	Code	Description
HOST Electric Fryer Single - 3kW 8Ltr	1		Apron
HOST Electric Fryer Single - 3kW 8Ltr	2		Apron Back Seal
HOST Electric Fryer Single - 3kW 8Ltr	3		Foot Plate
HOST Electric Fryer Single - 3kW 8Ltr	4		Black Rubber Feet (set 4)
HOST Electric Fryer Single - 3kW 8Ltr	5		Oil Pan
HOST Electric Fryer Single - 3kW 8Ltr	6		Oil Drain Pipe
HOST Electric Fryer Single - 3kW 8Ltr	7		Oil Drain Valve
HOST Electric Fryer Single - 3kW 8Ltr	8		Left / Right Support
HOST Electric Fryer Single - 3kW 8Ltr	9		Dowel
HOST Electric Fryer Single - 3kW 8Ltr	10		Hoarding
HOST Electric Fryer Single - 3kW 8Ltr	11		Floor
HOST Electric Fryer Single - 3kW 8Ltr	12		Upper Circumference
HOST Electric Fryer Single - 3kW 8Ltr	13		Patch
HOST Electric Fryer Single - 3kW 8Ltr	14		Electric Box Hoarding
HOST Electric Fryer Single - 3kW 8Ltr	15		Side Panel for Electric Box
HOST Electric Fryer Single - 3kW 8Ltr	16		Side Panel
HOST Electric Fryer Single - 3kW 8Ltr	17		Sealing Plate
HOST Electric Fryer Single - 3kW 8Ltr	18		Electric Heating Pipe
HOST Electric Fryer Single - 3kW 8Ltr	19		Rubber Sleeve
HOST Electric Fryer Single - 3kW 8Ltr	20		Basket Hanging Pole
HOST Electric Fryer Single - 3kW 8Ltr	21		Switch
HOST Electric Fryer Single - 3kW 8Ltr	22		Knob
HOST Electric Fryer Single - 3kW 8Ltr	23		Indicator Light
HOST Electric Fryer Single - 3kW 8Ltr	24		Left / Right Stiffening Plate
HOST Electric Fryer Single - 3kW 8Ltr	25		Travel Switch
HOST Electric Fryer Single - 3kW 8Ltr	26		Spring Plunger
HOST Electric Fryer Single - 3kW 8Ltr	27		Flat Net
HOST Electric Fryer Single - 3kW 8Ltr	28		Handle
HOST Electric Fryer Single - 3kW 8Ltr	29		Cover
HOST Electric Fryer Single - 3kW 8Ltr	30		Temperature Limiter
HOST Electric Fryer Single - 3kW 8Ltr	31		Circuit Board
HOST Electric Fryer Single - 3kW 8Ltr	32		EGO Thermostat
HOST Electric Fryer Single - 3kW 8Ltr	33		Basket
HOST Electric Fryer Single - 3kW 8Ltr	34		Cylinder Retainer Plate
HOST Electric Fryer Single - 3kW 8Ltr	35		Oil Cylinder Butt Weld