





























Machine	Explode	Code	Description
HOST Double Slice Conveyor Toaster	1		Governor
HOST Double Slice Conveyor Toaster	2		Indicator Light
HOST Double Slice Conveyor Toaster	3		Knob of Scaler
HOST Double Slice Conveyor Toaster	4		Knob Protection Box
HOST Double Slice Conveyor Toaster	5		Knob of 3 Gear
HOST Double Slice Conveyor Toaster	6		3 Gear Switch
HOST Double Slice Conveyor Toaster	7		Slag Collecting Pan
HOST Double Slice Conveyor Toaster	8		Chain Net
HOST Double Slice Conveyor Toaster	9		Space Truss
HOST Double Slice Conveyor Toaster	10		Terminal
HOST Double Slice Conveyor Toaster	11		Lower Heater
HOST Double Slice Conveyor Toaster	12		Upper Heater
HOST Double Slice Conveyor Toaster	13		Front Chain Net Rod
HOST Double Slice Conveyor Toaster	14		Rear Chain Net Rod
HOST Double Slice Conveyor Toaster	15		Inner Top Cover
HOST Double Slice Conveyor Toaster	16		Top Cover
HOST Double Slice Conveyor Toaster	17		Rear Radiator Plate
HOST Double Slice Conveyor Toaster	18		Hoarding
HOST Double Slice Conveyor Toaster	19		Rear Cover Plate
HOST Double Slice Conveyor Toaster	20		Rear Feeder Plate
HOST Double Slice Conveyor Toaster	21		Undercut Board
HOST Double Slice Conveyor Toaster	22		Shaft Seat
HOST Double Slice Conveyor Toaster	23		Shaft Gear
HOST Double Slice Conveyor Toaster	24		Drive Chain
HOST Double Slice Conveyor Toaster	25		Motor Gear
HOST Double Slice Conveyor Toaster	26		Electrical Machinery
HOST Double Slice Conveyor Toaster	27		Feet
HOST Double Slice Conveyor Toaster	28		Furnace Body
HOST Double Slice Conveyor Toaster	29		Bottom Sealing Plate
HOST Double Slice Conveyor Toaster	30		Power Cord
HOST Double Slice Conveyor Toaster	31		Fan