



















Machine	Explode	Code	Description
HOST0644IC - HOST Commercial Ice Crusher	1		Lid
HOST0644IC - HOST Commercial Ice Crusher	2		Magnet
HOST0644IC - HOST Commercial Ice Crusher	3		Cover
HOST0644IC - HOST Commercial Ice Crusher	4	AM374	Microswitch
HOST0644IC - HOST Commercial Ice Crusher	5		Connection
HOST0644IC - HOST Commercial Ice Crusher	6		Screw
HOST0644IC - HOST Commercial Ice Crusher	7		Sleeve
HOST0644IC - HOST Commercial Ice Crusher	8		Safety Arm
HOST0644IC - HOST Commercial Ice Crusher	9		Upper Spout
HOST0644IC - HOST Commercial Ice Crusher	10		Spout
HOST0644IC - HOST Commercial Ice Crusher	11	AM375	Oil Seal
HOST0644IC - HOST Commercial Ice Crusher	12		Steel Sheath
HOST0644IC - HOST Commercial Ice Crusher	13		Screw
HOST0644IC - HOST Commercial Ice Crusher	14		Motor Upper Cover
HOST0644IC - HOST Commercial Ice Crusher	15, 16		Cable Tie
HOST0644IC - HOST Commercial Ice Crusher	17		Power Cord
HOST0644IC - HOST Commercial Ice Crusher	18	AM376	On-Off Switch
HOST0644IC - HOST Commercial Ice Crusher	19	AM377	Circuit Board
HOST0644IC - HOST Commercial Ice Crusher	20	AM378	Motor
HOST0644IC - HOST Commercial Ice Crusher	21		Bottom Base
HOST0644IC - HOST Commercial Ice Crusher	22	AM379	Rubber Feet (set 4)
HOST0644IC - HOST Commercial Ice Crusher	23		Screw
HOST0644IC - HOST Commercial Ice Crusher	24	AM380	Blade
HOST0644IC - HOST Commercial Ice Crusher	25		Screw
HOST0644IC - HOST Commercial Ice Crusher	26		Baffle
HOST0644IC - HOST Commercial Ice Crusher	27		Container