













Machine	Explode	Code	Description
HOST0681CM - HOST Crepe Maker	1	AP092	Grilled Plate
HOST0681CM - HOST Crepe Maker	2	AK209	Heating Element
HOST0681CM - HOST Crepe Maker	3		Heat Pipe Pressure Plate
HOST0681CM - HOST Crepe Maker	4		Insulation Panel
HOST0681CM - HOST Crepe Maker	5		Body Frame
HOST0681CM - HOST Crepe Maker	6		Screw Rod
HOST0681CM - HOST Crepe Maker	7		Nut
HOST0681CM - HOST Crepe Maker	8	AK022	Indicator Lights (Green & Red)
HOST0681CM - HOST Crepe Maker	9	AK033	320°C Thermal Cut Out
HOST0681CM - HOST Crepe Maker	10	AK031	300°C Thermostat
HOST0681CM - HOST Crepe Maker	11		Knob
HOST0681CM - HOST Crepe Maker	12	AK210	Drip Tray
HOST0681CM - HOST Crepe Maker	13	AL187	Power Cord Connector
HOST0681CM - HOST Crepe Maker	14		UK Power Cord
HOST0681CM - HOST Crepe Maker	15	AK025	Terminal
HOST0681CM - HOST Crepe Maker	16	AK211	Rubber Feet (set 4)
HOST0681CM - HOST Crepe Maker	17		Inner Cover
HOST0681CM - HOST Crepe Maker	18		Bottom Plate
HOST0681CM - HOST Crepe Maker	19		Probe Clamp Plate
HOST0681CM - HOST Crepe Maker	20		Stainless Steel Fixing Screw
HOST0681CM - HOST Crepe Maker	21		Nut