



Machine	Explode	Code	Description
HOST0770WA - HOST Water Boiler - 8Ltr	1		Display Board
HOST0770WA - HOST Water Boiler - 8Ltr	2		PCB Board
HOST0770WA - HOST Water Boiler - 8Ltr	3	AK961	Tap incl. Washer & Nut
HOST0770WA - HOST Water Boiler - 8Ltr	4	AK962	Water Pan
HOST0770WA - HOST Water Boiler - 8Ltr	5	AK963	Water Temperature Sensor
HOST0770WA - HOST Water Boiler - 8Ltr	6	AK964	Water Level Sensor
HOST0770WA - HOST Water Boiler - 8Ltr	7	AK965	Inlet Value
HOST0770WA - HOST Water Boiler - 8Ltr	8	AK966	Heating Element
HOST0770WA - HOST Water Boiler - 8Ltr	9	AK967	Power Cord
HOST0770WA - HOST Water Boiler - 8Ltr	10	AK968	WRAS Water Inlet Pipe
HOST0770WA - HOST Water Boiler - 8Ltr	11	AK969	Feet (set 4)