

C20 Extra Strong Detergent for Ovens

Detergent for oven

Developed by Electrolux Professional to ensure the best cleaning and hygiene of your oven.



Applications

Ovens with integrated washing system



Description

- High degreasing power for ovens with integrated washing cycle
- Eco-friendly chemical substance with revised formulation without EDTA
- Guarantee of reliability without the risk of premature breakage of parts due to the use of chemicals
- Thoroughly field-tested by industry experts
- Ergonomic package with two 5 l tanks, for easy handling and storage

Chemical-physical characteristics

Appearance	Clear liquid
Colour	Yellowish
Odour	Faint characteristic
Relative density	1.17 g/ml
Water solubility	Complete
pH	>13



Scan the QR code to view the safety data sheet



Instructions for use

1. Wear protective gloves and safety glasses
2. Put **C20 Extra Strong Detergent for Ovens** into the appropriate doser of the integrated cleaning system.
3. Select the appropriate wash cycle and pressstart.

Package and code

2 x 5L cans – code 0S2282

Warnings:

- the product is for professional use only; do not use in domestic appliances.
- transport and storage must be done only in the original package, upright position.
- do not expose to sunlight and freezing temperatures.
- do not transfer in other bottles.
- do not mix with other products.
- to be used within 30 months after the production date.
- the package and containers are totally recyclable.
- please handle the emptied material according to the local recycling regulation.