

HOST

Ice Crusher

Instruction manual

Model:

HOST0643IC



Read this instruction
manual carefully
before use

Safety Instructions

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - BS EN Codes of Practice
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT immerse the appliance in water.
- This appliance is only used for crushing ice. Do not use the appliance for anything other than its intended use.
- Switch off and disconnect from power supply when not in use, before assembling or disassembling, and before cleaning.
- Avoid contacting moving parts. Never place fingers or other utensils into feeding or discharge areas.
- Ensure to check ice chute for the presence of foreign objects before use. Use original attachments only to prevent any damage.
- Suitable for indoor use only.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.


- If the power cord is damaged, it must be replaced by a recommended qualified technician in order to avoid a hazard.
- HOST recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Insulation Continuity and Functional Testing.
- HOST recommend that this product is connected to a circuit protected by an appropriate RCD (Residual Current Device).

Installation

1. Remove the appliance from the packaging. Make sure that all protective plastic film and plastic coatings are thoroughly removed from all surfaces.
2. Place the appliance on a flat surface, ensuring the suction feet on the bottom get a firm grip.
3. Put the ice chute into the chute socket in place.
4. Push the ice container into the lower part of the unit.

Note: The appliance will not work unless the ice container is secured into position.

5. Pour warm water through the ice chute to rinse the appliance thoroughly.
6. Remove and clean the ice chute and ice container. Dry well and re-locate into the appliance.



Operation

1. Connect to the mains power supply and turn the power switch On (I).
2. Drop ice cubes into the ice chute to start crushing. **(Note: Suitable for cubes up to 2x2x2 cm)**

WARNING: The blades of the crusher are self feeding! Do not attempt to push cubes into blades with hand or instrument.

3. After use, turn the power switch Off (O) and disconnect from power supply.

It is recommended that the appliance is allowed to cool after each cycle. For an operation cycle of 3 minutes the recommended cool down time is 10 minutes.

Ice blockage

1. Should a large cube get blocked in the crushing unit, set the power switch to the OFF position (O) and unplug the unit.
2. Pour warm water through the ice chute to melt ice blockage.
3. Re-plug and re-start the appliance.

Cleaning, Care & Maintenance

- **Always turn off and disconnect the appliance from the power supply before cleaning.**
- Pour warm water through the ice chute to rinse the appliance thoroughly.
- Wipe the appliance housing with a damp cloth. Dry well afterwards.

Troubleshooting

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace plug or lead
	Fuse in the plug has blown	Replace the fuse
	Mains power supply fault	Check mains power supply

Service

Should your appliance have a fault, please visit the Service section of the HOST website.

Technical Specifications

Model	Voltage	Power	Current	Ice container capacity	Weight (kg)	Dimensions (H x W x D) (mm)	Largest ice cube
HOST0643IC	220-240V~50/60Hz	60-80W	1A	12 Cup	3.71	460 x 220 x 170	2 x 2 x 2 cm

Due to our continuing program of research and development, the specifications herein are subject to change without notice.

Electrical Wiring

This appliance is supplied with a 3 pin BS1363 plug and lead.

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



HOST parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of HOST.
Every effort is made to ensure all details are correct at the time of going to press, however, HOST reserve the right to change specifications without notice.

HOST UKCA Declaration of Conformity



We {Host} of {Host House, Chepstow, NP16 6UP} hereby declare that the equipment is in conformity with the requirements of the following Regulations:

- Electrical Equipment (Safety) Regulations 2016
- Electromagnetic Compatibility Regulations 2016
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012
- Ecodesign for Energy-related Products Regulations 2010 (as amended)

We hereby declare that:

Equipment Model number **HOST0643IC** **12kg/hr Ice Crusher**

is in conformity with the applicable requirements of the following documents

Ref. No.	Edition/date
BS EN 60335-1	2012 +A11:2014 +A13:2017 +A1:2019 +A14:2019 +A2:2019
BS EN 60335-2-14	2006 +A1:2008 +A11:2012 +A12:2016
BS EN 62233	2008
BS EN 55014-1	2017
BS EN 55014-2	2015
BS EN IEC 61000-3-2	2019
BS EN 61000-3-3	2013 +A1:2019
BS EN 50564	2011

I hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications and is in accordance with the requirements of the Regulations:

Signed by: 

Full Name **Jess Attree**

Title: **General Manager**

Location: **Chepstow, Great Britain**

Date: **17th June 2022**



www.host-appliances.com

HOST0643IC_EN_A5_v1_2022/09/05