

HOST

Heat Shade

Instruction manual

Model:

HOST0761HC

HOST0762HS

HOST0763DC

HOST0764DS



Read this instruction
manual carefully
before use

Safety Instructions

Electrical requirements:

This appliance should only be connected to the mains electricity supply by a qualified electrician. Hardwire the Heat Shade into a suitable power supply with correct voltage and sufficient power capacity. Refer to the product label (serial plate) on the warmer for voltage and wattage requirements.

- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - BS EN Codes of Practice
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations
- **Caution! Hot surface!** 
- Always switch off and disconnect the power supply to the appliance when not in use, before cleaning and any maintaining/service procedure.
- This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as drapes and other furnishings, away from appliance.
- Extreme caution is necessary when any appliance is used by or near children and whenever the appliance is left unattended.
- This appliance has electrical parts. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- DO NOT obstruct or cover the appliance in any way when in use.
- Clean the appliance thoroughly before and after each use following the cleaning instructions provided in this manual.

- Do not operate any appliance with a damaged cord if the appliance malfunctions or has been dropped / damaged. Return appliance to an authorised service facility for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors. This appliance is not intended for wet or moist locations. Never locate appliance where it may fall into water.
- For indoor use only.
- Avoid the use of extension cords. Do not run cord under carpeting, runners, or the like. Arrange cord away from traffic area and where it will not create a trip hazard.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- HOST recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- HOST recommend that this product is connected to a circuit protected by an appropriate RCD (Residual Current Device).



Warning:

This unit is only suitable for R40 or BR40 type incandescent lamps.

The lamp is excluded from the warranty.

Preparation

1. Remove the Heat Shade assembly from the carton.
2. Remove tape and protective packaging from all surfaces of unit.
3. Make sure the installation site provides the proper installation clearances for the unit.

Installation

- Never mount the appliance in humid or wet environment.
- Mount the appliance in an easily accessible location, so it may be used when needed for keeping food warm.
- When mounting the appliance, make sure that walls, partition walls, kitchen furniture, decorative edges, etc. that are nearby are not made of flammable materials. Otherwise, they must be covered with a non-flammable, heat isolating material.
- **When mounting, observe fire-fighting regulations in force in the country of installation.**

Note:

- **Fixings not included.**
- **You may unscrew the threaded nuts to adjust the length to fit your requirements.**

Operation

Turn the appliance On/Off using the power switch (I/O) located on the top of the lamp shade.

Note: The appliance only maintains temperature. It does NOT continue to cook food.

Cleaning, Care & Maintenance

- **Proper maintenance plays an important part in the life span and functioning of the shade.**
- **The heat shade must not be cleaned by a water jet.**
- **Disconnect the heat shade from the power source prior to cleaning and any maintenance. Ensure the surface is cool.**

- This unit can be cleaned with a damp sponge and mild soap. Rinse with clean water and wipe dry.
- Do not immerse in water or other liquid.

Heat bulb replacement

Each standard Heat Shade is suitable for a clear or infrared heat bulb rated at or below 250 watts.

1. To replace a bulb, place the power switch (I/O) in the OFF position (O) and allow the bulb and shade to cool completely.
2. Bulbs have a threaded base. Unscrew the bulb counter-clockwise from the unit and replace with a new bulb.

Troubleshooting

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check the unit is hardwired correctly and switched on
	Lead is damaged	Replace lead
	Mains power supply fault	Check mains power supply
	Lamp expired	Replace lamp of the same type

Service

Should your appliance have a fault, please visit the Service section of the HOST website.

Technical Specifications

Model	Voltage	Power	Range of cord (mm)	Dimensions (H x W x D) (mm)	Weight
HOST0761HC	220-240V 50/60Hz	250W	280 - 1520	310 x 177 x 177	1.05kg
HOST0762HS	220-240V 50/60Hz	250W	280 - 1520	310 x 177 x 177	1.05kg
HOST0763DC	220-240V 50/60Hz	250W	280 - 1520	295 x 292 x 292	1.36kg
HOST0764DS	220-240V 50/60Hz	250W	280 - 1520	295 x 292 x 292	1.36kg

Due to our continuing program of research and development, the specifications herein are subject to change without notice.

Electrical Wiring

This appliance is supplied unplugged and requires hardwiring to a suitable electrical power supply.

The appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Connection to a suitable power supply should only be carried out by a qualified and competent electrical engineer.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



HOST parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of HOST.
Every effort is made to ensure all details are correct at the time of going to press, however, HOST reserve the right to change specifications without notice.

UK
CA

- Electrical Equipment (Safety) Regulations 2016
- Electromagnetic Compatibility Regulations 2016
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

Equipment Model number	HOST0761HC	Copper Retractable Heat Shade
	HOST0762HS	Silver Retractable Heat Shade
	HOST0763DC	Copper Retractable Dome Heat Shades
	HOST0764DS	Silver Retractable Dome Heat Shades

Ref. No.	Edition/date
BS EN 60598-1	2015
BS EN 60598-2-1	1989
BS EN 62493	2015
BS EN 55015	2013 +A1:2015
BS EN 61547	2009
BS EN IEC 61000-3-2	2019
BS EN 61000-3-3	2013 +A1:2019

DocuSigned by:

Signed by:

Full Name **Jess Attree**

Title: General Manager

Location: Chepstow, Great Britain

Date: 20th June 2022



www.host-appliances.com

HOST0761HC to HOST0764DS_EN_A5_v1_2022/08/12