

HOST

Bain Marie

Instruction manual

Model:

HOST0501BN

HOST0502BT

HOST0503BP

HOST0504BB

HOST0505BR



**Read this instruction
manual carefully
before use**

Safety Instructions


- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - BS EN Codes of Practice
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations
- DO NOT immerse the appliance in water, or use jet/pressure washers to clean it.
- DO NOT touch hot surfaces with bare hands. Always use the handles/protective gloves.
- DO NOT overfill the appliance. Keep the water level below the 'MAX' level.
- DO NOT allow the water level to drop below the 'MIN' level during operation.
- DO NOT move the appliance when it contains hot liquid.
- DO NOT use the appliance for anything other than its intended use.
- Always switch off and disconnect the power supply to the appliance when not in use.
- Not suitable for outdoor use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a recommended qualified technician in order to avoid a hazard.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- **Warning:** Opening the drain cock will lead to the outflow of the hot contents of the Bain Marie.
- HOST recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- HOST recommend that this product is connected to a circuit protected by an appropriate RCD (Residual Current Device).

Product Description

Model	Tap	Pans	Pots
HOST0503BP	✗	✓	✗
HOST0504BB	✓	✓	✗
HOST0501BN	✗	✗	✗
HOST0502BT	✓	✗	✗
HOST0505BR	✗	✗	✓

Operation



1. Connect the appliance to the power supply.
2. Fill the tank with water to a level between the 'MIN' and 'MAX' marks on the inside of the tank.

Note: HOST recommend that fresh water should be used each time.

3. Switch the power switch to the On position [I].
4. Turn the thermostat to the desired temperature to heat-up the appliance. The heat indicator light will turn on.
5. Once the appliance has heated the water, the heat indicator light will turn Off.
6. Reduce the heat setting on the Thermostat to maintain temperature.

WARNING: Do not allow the water to drop below the 'MIN' level during operation. Otherwise, severe damage to the heating element could result.

Maintaining Water Levels

It is important to regularly check the water level in the tank.

- Always keep the water level above the 'MIN' mark on the inside of the tank during operation.
- Damage to the heating element can occur if the tank boils dry and the element may have to be replaced. This is not covered by the HOST warranty.

Emptying the Appliance

Note: Always switch the appliance off and allow the water to cool before emptying.

HOST0504BB/HOST0502BT - Turn on the tap to drain the water. Ensure a suitable container is used to collect the water.

HOST0503BP/HOST0501BN/HOST0505BR - Use a suitable container to remove the water from the appliance.

Thermal Cut-Out Reset

This appliance is fitted with a Thermal Cut-Out safety feature. Should the temperature exceed safe levels the appliance will automatically cut power.

The thermal Cut-out switch is located on the rear of the appliance. To reset the appliance after a sufficient cool-down period:

1. Unscrew the reset switch cover.
2. Press the small reset switch down until it clicks, using a blunt pointed instrument.
3. The appliance is now reset and can be used as normal.

Cleaning, Care & Maintenance

WARNING: Always turn off and disconnect the appliance from the power supply before cleaning.

Always allow the appliance to cool before emptying or cleaning.

- Wipe down the exterior of the appliance with a damp cloth.
- Some cleaning agents may cause damage when used for a prolonged period on stainless steel. Use a suitable stainless steel cleaner. Daily cleaning is recommended.
- Wash all removable parts in warm, soapy water.
- Dry the exterior thoroughly.

De-scaling

To maintain energy efficiency and prolong the life of the appliance, regular de-scaling is needed.

- Pour a solution of neutral cleaner and water into the appliance.
- Brush gently with a soft brush.
- Discard the solution and flush out thoroughly with clean water to remove any solution residue.

- Wipe dry the appliance, especially the bottom part of the water tank.

Note: Use a suitable cleaner and always follow the instructions on the cleaner container.

HOST recommend that this appliance is de-scaled every 3 months or more often in hard water areas.

IMPORTANT: Failure to de-scale or maintain will invalidate your guarantee.

Troubleshooting

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace plug or lead
	Fuse in the plug has blown	Replace the fuse
	Mains power supply fault	Check mains power supply
	Thermal cut-out switch has activated	Reset Thermal cut-out switch
	The thermostat has not been set correctly	Set the thermostat to a higher temperature
	The heating element has failed	Replace heating element

Service

Should your appliance have a fault, please visit the Service section of the HOST website.

Technical Specifications

Model	Voltage	Power	Current	Dimensions (H x W x D) (mm)	Weight (kg)
HOST0503BP	220-240V~ 50/60Hz	1100-1300W	5.2A	246 x 340 x 598	10.4
HOST0504BB					10.7
HOST0501BN					7.8
HOST0502BT					8.1
HOST0505BR					10.5

Due to our continuing program of research and development, the specifications herein are subject to change without notice.

Electrical Wiring

The appliance is supplied with a 3 pin BS1363 plug and lead.

The plug is to be connected to a suitable mains socket.

The appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



HOST parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of HOST.
Every effort is made to ensure all details are correct at the time of going to press, however, HOST reserve the right to change specifications without notice.

HOST UKCA Declaration of Conformity



We {Host} of {Host House, Chepstow, NP16 6UP} hereby declare that the equipment is in conformity with the requirements of the following Regulations:

- Electrical Equipment (Safety) Regulations 2016
- Electromagnetic Compatibility Regulations 2016
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

We hereby declare that:

Equipment Model number	HOST0501BN	Bain Marie
	HOST0502BT	Bain Marie with Drain Tap
	HOST0503BP	Bain Marie with GN Pans
	HOST0504BB	Bain Marie with Drain Tap and GN Pans
	HOST0505BR	Bain Marie with Pots

is in conformity with the applicable requirements of the following documents

Ref. No.	Edition/date
BS EN 60335-1	2012 +A11:2014 +A13:2017 +A1:2019 +A14:2019 +A2:2019
BS EN 60335-2-50	2003+A1:2008
BS EN 62233	2008
BS EN IEC 55014-1	2021
BS EN IEC 55014-2	2021
BS EN IEC 61000-3-2	2019
BS EN 61000-3-3	2013 +A1:2019

I hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications and is in accordance with the requirements of the Regulations:

Signed by: 

Full Name **Jess Attree**
Title: **General Manager**
Location: **Chepstow, Great Britain**
Date: **15th June 2022**



www.host-appliances.com

HOST0501BN to HOST0505BR_EN_A5_v1_2022/08/12