

MAT20MN 50hz Default Cycle & Options Chart

CYCLES

Normal Eco Cycle

Cycle Time	Cycle Phase:	Spin Fill	Static Fill	Wash Agitation	Drain	Spin & Drain	Bath Rinse Spin Fill	Bath Rinse Static Fill	Agitation	Drain	Spin & Drain
32 min.	Time, minutes:	2	1.3	10	2	1	2	0.5	2	2	9
	Lid Unlocked:	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	No

Normal Deep Water Cycle

Cycle Time	Cycle Phase:	Spin Fill	Static Fill	Wash Agitation	Drain	Spin & Drain	Deep Bath Rinse Spin Fill	Deep Bath Rinse Static Fill	Agitation	Drain	Spin & Drain
32.5 min.	Time, minutes:	3.25	2	9	2	1	3.25	2	2	2	6
	Lid Unlocked:	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	No

Delicates Cycle

Cycle Time	Cycle Phase:	Spin Fill	Static Fill	Wash Agitation	Drain	Spin & Drain	Deep Bath Rinse Spin Fill	Deep Bath Rinse Static Fill	Agitation	Drain	Spin & Drain
29.5 min.	Time, minutes:	3.25	2	6	2	1	3.25	2	2	2	6
	Lid Unlocked:	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	No

PowerWash Cycle

Cycle Time	Cycle Phase:	Spin Fill	Static Fill	Wash Agitation	Drain	Spin & Drain	Deep Bath Rinse Spin Fill	Deep Bath Rinse Static Fill	Agitation	Drain	Spin & Drain
35.5 min.	Time, minutes:	3.25	2	12	2	1	3.25	2	2	2	6
	Lid Unlocked:	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	No

Bulky / Towels

Cycle Time	Cycle Phase:	Spin Fill	Static Fill	Agitation	Drain	Spin & Drain	Deep Bath Rinse Spin Fill	Deep Bath Rinse Static Fill	Agitation	Drain	Spin & Drain
33.25 min.	Time, minutes:	3.25	2.75	9	2	1	3.25	2	2	2	6
	Lid Unlocked:	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	No

Rinse & Spin Cycle

Cycle Time	Cycle Phase:	Deep Bath Rinse Spin Fill	Deep Bath Rinse Static Fill	Agitation	Drain	Spin & Drain
15.25 min.	Time, minutes:	3.25	2	2	2	6
	Lid Unlocked:	Yes	Yes	Yes	Yes	No

Drain & Spin Cycle

Cycle Time	Cycle Phase:	Drain	Spin & Drain
8 min.	Time, minutes:	2	6
	Lid Unlocked:	Yes	No

*End user can access machine during wash, fill, deep bath rinse simply by lifting lid and closing again.
Lid locks during spins and spray rinses only, machine can be paused by holding start for 3 sec.
** Cycle times are approximate and can vary based on conditions

MAT20MN 50hz Default Cycle & Options Chart

Spin Chart (RPM)		
Cycle	Initial	Final
Normal Eco	500	700
Mixed	500	700
Delicates	250	500
PowerWash	500	700
Bulky / Towels	500	700
Rinse & Spin	N/A	700
Drain & Spin	N/A	700

*End user can access machine during wash, fill, deep bath rinse simply by lifting lid and closing again.
Lid locks during spins and spray rinses only, machine can be paused by holding start for 3 sec.

OPTIONS

Temperature

Normal Eco	Temp F	Temp C
Tap Cold	60	15.6
Cold	62	16.7
Cool	65	18.3
Warm	77	25.0
Hot	110	43.3

Deep Water Cycles	Temp F	Temp C
Tap Cold	60	15.6
Cold	65	18.3
Cool	80	26.6
Warm	90	32.2
Hot	130	54.4