










Machine	Explode	Code	Description
CT012-A Apuro Double Induction Fryer - 2x3kW	1		Back of Control Box
CT012-A Apuro Double Induction Fryer - 2x3kW	2	AH371	Indicator Light
CT012-A Apuro Double Induction Fryer - 2x3kW	3	AH372	Power Switch
CT012-A Apuro Double Induction Fryer - 2x3kW	4	AH373	Liquid Expansion Thermostat
CT012-A Apuro Double Induction Fryer - 2x3kW	5	AH374	Indicator Light Connect Wire
CT012-A Apuro Double Induction Fryer - 2x3kW	6		Control Box
CT012-A Apuro Double Induction Fryer - 2x3kW	7	AL175	Oil Temperature Sensor - AP434
CT012-A Apuro Double Induction Fryer - 2x3kW	28		PCB
CT012-A Apuro Double Induction Fryer - 2x3kW	8		Tank
CT012-A Apuro Double Induction Fryer - 2x3kW	9	AH375	Power Connect Wire
CT012-A Apuro Double Induction Fryer - 2x3kW	10	AH376	Adjuster
CT012-A Apuro Double Induction Fryer - 2x3kW	11	AH377	Knob Set
CT012-A Apuro Double Induction Fryer - 2x3kW	12	AJ530	Handle
CT012-A Apuro Double Induction Fryer - 2x3kW	13	AL942	Lid
CT012-A Apuro Double Induction Fryer - 2x3kW	14	AP688	Fixed Support for Sensor
CT012-A Apuro Double Induction Fryer - 2x3kW	15	AH378	Filter
CT012-A Apuro Double Induction Fryer - 2x3kW	16	AH379	Basket
CT012-A Apuro Double Induction Fryer - 2x3kW	17	AH380	Tubing Fixing Sheet
CT012-A Apuro Double Induction Fryer - 2x3kW	18		Tap Cover
CT012-A Apuro Double Induction Fryer - 2x3kW	19		Tap
CT012-A Apuro Double Induction Fryer - 2x3kW	20		Stainless Steel Housing
CT012-A Apuro Double Induction Fryer - 2x3kW	21	AN395	Equal Potential Terminal
CT012-A Apuro Double Induction Fryer - 2x3kW	22	AJ531	Inside Glass Plate
CT012-A Apuro Double Induction Fryer - 2x3kW	23	AH381	Thermostat Connect Wire
CT012-A Apuro Double Induction Fryer - 2x3kW	24	AJ532	Heating Coil
CT012-A Apuro Double Induction Fryer - 2x3kW	25	AJ533	Spring
CT012-A Apuro Double Induction Fryer - 2x3kW	26	AH382	Fan
CT012-A Apuro Double Induction Fryer - 2x3kW	27	AH383	11A Sensor
CT012-A Apuro Double Induction Fryer - 2x3kW	29	AH385	Earth Wire
CT012-A Apuro Double Induction Fryer - 2x3kW	30	AJ534	Inside Plastic Housing
CT012-A Apuro Double Induction Fryer - 2x3kW	31		Power Cord Lock
CT012-A Apuro Double Induction Fryer - 2x3kW	32		Power Cord
CT012-A Apuro Double Induction Fryer - 2x3kW	33		Plug Cord Fixing
CT012-A Apuro Double Induction Fryer - 2x3kW	34		Bottom Plate
CT012-A Apuro Double Induction Fryer - 2x3kW	35	AJ536	Bottom Filter
CT012-A Apuro Double Induction Fryer - 2x3kW	36	AH386	Feet
CT012-A Apuro Double Induction Fryer - 2x3kW	37		Control Panel Sticker