


Machine	Explode	Code	Description
Apuro Bistro Double Contact Grill	1		Front Panel
Apuro Bistro Double Contact Grill	2	AS325	Thermostat
Apuro Bistro Double Contact Grill	3	AU366	Oil Box
Apuro Bistro Double Contact Grill	4		Bottom Heater Cover Plate
Apuro Bistro Double Contact Grill	5	AS329	Lower Heater
Apuro Bistro Double Contact Grill	6	AS332	Indicator Light
Apuro Bistro Double Contact Grill	7	AS333	Switch-old version
Apuro Bistro Double Contact Grill	7	AW124	Switch-new version
Apuro Bistro Double Contact Grill	8	AS337	Black Rubber Feet (set 4)
Apuro Bistro Double Contact Grill	9		Bottom Sealing Plate
Apuro Bistro Double Contact Grill	10		Cotton Sealing Board
Apuro Bistro Double Contact Grill	11		Terminal
Apuro Bistro Double Contact Grill	12		Hoarding
Apuro Bistro Double Contact Grill	13	AS334	Hi-Limit
Apuro Bistro Double Contact Grill	14		Bottom Griddle (Ribbed) for CU604
Apuro Bistro Double Contact Grill	14	AW591	Bottom Griddle (Flat) for CU605 CU606
Apuro Bistro Double Contact Grill	15		Top Griddle (Ribbed) for CU604 CU606
Apuro Bistro Double Contact Grill	15	AW770	Top Griddle (Flat) for CU605
Apuro Bistro Double Contact Grill	16	AS328	Upper Heater
Apuro Bistro Double Contact Grill	17	AU999	Handle Assembly Left
Apuro Bistro Double Contact Grill	17	AS322	Handle Assembly Right
Apuro Bistro Double Contact Grill	18	AW028	Upper Shaft
Apuro Bistro Double Contact Grill	19	AW383	Spring
Apuro Bistro Double Contact Grill	20		Top Cover
Apuro Bistro Double Contact Grill	21	AW986	Protect Pipe
Apuro Bistro Double Contact Grill	22	AS344	Knob
Apuro Bistro Double Contact Grill	N/A		AUS Power Cord
Apuro Bistro Double Contact Grill	N/A	AW291	Allen Key

Circuit Diagram



No.	Code	Description
1	SA	Power Switch
2	WK1-WK2	Thermostat
3	XW1-XW2	Hi-limit
4	HL1-HL2	Heating indicator light
5	EH1-EH3	Up heater
6	EH2-EH4	Down heater