




Machine	Explode	Code	Description
Apuro Double Contact Grill	1		Front Panel
Apuro Double Contact Grill	2	AS325	Thermostat
Apuro Double Contact Grill	3	AU366	Oil Box
Apuro Double Contact Grill	4		Bottom Heater Cover Plate
Apuro Double Contact Grill	5	AS611	Lower Heater
Apuro Double Contact Grill	6	AS332	Indicator Light
Apuro Double Contact Grill	7	AS333	Switch-old version
Apuro Double Contact Grill	7	AW124	Switch-new version
Apuro Double Contact Grill	8	AS337	Black Rubber Feet (set 4)
Apuro Double Contact Grill	9		Bottom Sealing Plate
Apuro Double Contact Grill	10		Cotton Sealing Board
Apuro Double Contact Grill	11		Terminal
Apuro Double Contact Grill	12		Hoarding
Apuro Double Contact Grill	13	AS334	Hi-Limit
Apuro Double Contact Grill	14	AW591	Lower Griddle Plate (Flat) for CU610 CU612
Apuro Double Contact Grill	14		Lower Griddle Plate (Ribbed) for CU611
Apuro Double Contact Grill	14		Lower Griddle Plate (Ribbed Left/Flat Right) for CU613
Apuro Double Contact Grill	15		Upper Griddle Plate (Flat) for CU610 CU613
Apuro Double Contact Grill	15		Upper Griddle Plate (Ribbed) for CU611 CU612 CU613
Apuro Double Contact Grill	16	AS609	Upper Heater
Apuro Double Contact Grill	17	AU999	Handle Assembly Left
Apuro Double Contact Grill	17	AS322	Handle Assembly Right
Apuro Double Contact Grill	18	AW028	Upper Shaft
Apuro Double Contact Grill	19	AW383	Spring
Apuro Double Contact Grill	20		Top Cover
Apuro Double Contact Grill	21	AW986	Protect Pipe
Apuro Double Contact Grill	22	AT583	Circuit Board
Apuro Double Contact Grill	23	AS344	Knob
Apuro Double Contact Grill	N/A		AUS Power Cord
Apuro Double Contact Grill	N/A	AW291	Allen Key