















Machine	Explode	Code	Description
CU619-A Apuro Double Fryer - 2x5Ltr	1		Apron
CU619-A Apuro Double Fryer - 2x5Ltr	2	AS337	Black Rubber Feet (set 4)
CU619-A Apuro Double Fryer - 2x5Ltr	3		Foot Plate
CU619-A Apuro Double Fryer - 2x5Ltr	4		Fretting Switch Roof
CU619-A Apuro Double Fryer - 2x5Ltr	5		Dowel
CU619-A Apuro Double Fryer - 2x5Ltr	6		Apron Back Plate
CU619-A Apuro Double Fryer - 2x5Ltr	7		Apron Crossbeam
CU619-A Apuro Double Fryer - 2x5Ltr	8		Electric Box Hoarding
CU619-A Apuro Double Fryer - 2x5Ltr	9		Side Panel for Electric Box
CU619-A Apuro Double Fryer - 2x5Ltr	10		Side Panel
CU619-A Apuro Double Fryer - 2x5Ltr	11		Electric Box Sealing Plate
CU619-A Apuro Double Fryer - 2x5Ltr	12		Heater
CU619-A Apuro Double Fryer - 2x5Ltr	13	AS341	Travel Switch
CU619-A Apuro Double Fryer - 2x5Ltr	14		Heater Protective Plate
CU619-A Apuro Double Fryer - 2x5Ltr	15	AS343	Cover
CU619-A Apuro Double Fryer - 2x5Ltr	16	AS333	Switch-old version
CU619-A Apuro Double Fryer - 2x5Ltr	16	AW124	Switch-From 413521-AU
CU619-A Apuro Double Fryer - 2x5Ltr	17	AS332	Indicator Light
CU619-A Apuro Double Fryer - 2x5Ltr	18	AS344	Knob
CU619-A Apuro Double Fryer - 2x5Ltr	19	AS324	Handle
CU619-A Apuro Double Fryer - 2x5Ltr	20		Rubber Sleeve
CU619-A Apuro Double Fryer - 2x5Ltr	21		Blasting Net Support Piece
CU619-A Apuro Double Fryer - 2x5Ltr	22	AS340	1/2 GN Pan
CU619-A Apuro Double Fryer - 2x5Ltr	23	AS335	Hi-Limit / Temperature Limiter
CU619-A Apuro Double Fryer - 2x5Ltr	24	AS327	EGO Thermostat
CU619-A Apuro Double Fryer - 2x5Ltr	25	AS346	Basket