




Machine	Explode	Code	Description
CU615-A Apuro Double Fryer - 2x3Ltr	1		Apron
CU615-A Apuro Double Fryer - 2x3Ltr	2	AS337	Black Rubber Feet (set 4)
CU615-A Apuro Double Fryer - 2x3Ltr	3		Foot Plate
CU615-A Apuro Double Fryer - 2x3Ltr	4		Fretting Switch Roof
CU615-A Apuro Double Fryer - 2x3Ltr	5		Dowel
CU615-A Apuro Double Fryer - 2x3Ltr	6		Apron Back Plate
CU615-A Apuro Double Fryer - 2x3Ltr	7		Apron Crossbeam
CU615-A Apuro Double Fryer - 2x3Ltr	8	AS339	1/3 GN Pan
CU615-A Apuro Double Fryer - 2x3Ltr	9	AS342	Cover
CU615-A Apuro Double Fryer - 2x3Ltr	10	AS324	Handle
CU615-A Apuro Double Fryer - 2x3Ltr	11		Electric Box Hoarding
CU615-A Apuro Double Fryer - 2x3Ltr	12		Side Panel for Electric Box
CU615-A Apuro Double Fryer - 2x3Ltr	13		Side Panel
CU615-A Apuro Double Fryer - 2x3Ltr	14		Electric Box Sealing Plate
CU615-A Apuro Double Fryer - 2x3Ltr	15	AU794	Heater
CU615-A Apuro Double Fryer - 2x3Ltr	16	AS341	Travel Switch
CU615-A Apuro Double Fryer - 2x3Ltr	17	AS333	Switch-old version
CU615-A Apuro Double Fryer - 2x3Ltr	17	AW124	Switch-new version
CU615-A Apuro Double Fryer - 2x3Ltr	18	AS344	Knob
CU615-A Apuro Double Fryer - 2x3Ltr	19	AS332	Indicator Light
CU615-A Apuro Double Fryer - 2x3Ltr	20	AY267	Blasting Net Support Piece
CU615-A Apuro Double Fryer - 2x3Ltr	21		Heater Guard Plate
CU615-A Apuro Double Fryer - 2x3Ltr	22	AS335	Hi-Limit / Temperature Limiter
CU615-A Apuro Double Fryer - 2x3Ltr	23	AS327	EGO Thermostat
CU615-A Apuro Double Fryer - 2x3Ltr	24	AS345	Basket
CU615-A Apuro Double Fryer - 2x3Ltr	25	AY280	Rubber Sleeve
CU615-A Apuro Double Fryer - 2x3Ltr	N/A		AUS Power Cord