




Machine	Explode	Code	Description
HX584-A Apuro Rise and Fall Salamander Grill	1		Top Cover Plate
HX584-A Apuro Rise and Fall Salamander Grill	2		Top Left Sealing Cotton Board
HX584-A Apuro Rise and Fall Salamander Grill	3		Top Right Sealing Cotton Board
HX584-A Apuro Rise and Fall Salamander Grill	4	AS831	Handle
HX584-A Apuro Rise and Fall Salamander Grill	5		Top Cover Welding Parts
HX584-A Apuro Rise and Fall Salamander Grill	6	AS832	Heating Element
HX584-A Apuro Rise and Fall Salamander Grill	7		Support Rod Fixing Plate
HX584-A Apuro Rise and Fall Salamander Grill	8		Electric Heating Tube Support Rod
HX584-A Apuro Rise and Fall Salamander Grill	9	AS833	Grilling Net
HX584-A Apuro Rise and Fall Salamander Grill	10	AW917	Crumb Tray
HX584-A Apuro Rise and Fall Salamander Grill	11		External Thread Bearing
HX584-A Apuro Rise and Fall Salamander Grill	12	AS009	Knob
HX584-A Apuro Rise and Fall Salamander Grill	12	AS011	Knob Core
HX584-A Apuro Rise and Fall Salamander Grill	13	AS007	Green Indicator Light
HX584-A Apuro Rise and Fall Salamander Grill	14	AS020	On/Off Switch
HX584-A Apuro Rise and Fall Salamander Grill	15	AS834	Temperature Controller
HX584-A Apuro Rise and Fall Salamander Grill	16	AS835	Temperature Cut Out
HX584-A Apuro Rise and Fall Salamander Grill	17		Bottom Plate
HX584-A Apuro Rise and Fall Salamander Grill	18	AK211	Rubber Feet (set 4)
HX584-A Apuro Rise and Fall Salamander Grill	19	AK025	Terminal Block
HX584-A Apuro Rise and Fall Salamander Grill	20		Sliding Axis
HX584-A Apuro Rise and Fall Salamander Grill	21		Buffer Pad
HX584-A Apuro Rise and Fall Salamander Grill	22		Short Axis
HX584-A Apuro Rise and Fall Salamander Grill	23		Sliding Rod
HX584-A Apuro Rise and Fall Salamander Grill	24		Rotating Shaft
HX584-A Apuro Rise and Fall Salamander Grill	25		Back Plate
HX584-A Apuro Rise and Fall Salamander Grill	26	AL187	Power Cable Head
HX584-A Apuro Rise and Fall Salamander Grill	27		AUS Power Cord
HX584-A Apuro Rise and Fall Salamander Grill	28	AS966	Screw-Optional
HX584-A Apuro Rise and Fall Salamander Grill	29		Wall Bracket-Optional
HX584-A Apuro Rise and Fall Salamander Grill	30		Fixed Seat
HX584-A Apuro Rise and Fall Salamander Grill	31		Counterweight Block
HX584-A Apuro Rise and Fall Salamander Grill	32		Linear Slider Bearing Seat
HX584-A Apuro Rise and Fall Salamander Grill	33		Bearing Seat
HX584-A Apuro Rise and Fall Salamander Grill	34		Long Axis
HX584-A Apuro Rise and Fall Salamander Grill	35		2' Sprocket
HX584-A Apuro Rise and Fall Salamander Grill	36		Sliding Pad
HX584-A Apuro Rise and Fall Salamander Grill	37		Line Crossing Seat
HX584-A Apuro Rise and Fall Salamander Grill	N/A	AW731	Wiring Loom