


**apuro**

**Conveyor Toaster**  
Instruction manual



**Model:**  
**CU629-A**

## Safety Instructions

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
  - Health and Safety at Work Legislation
  - Fire Precautions
  - Wiring Regulations
  - Building Regulations
- **Caution! Hot surface!** Do not touch! Take care when using or handling the appliance. 
- **Fire hazard! Bread can burn!** The appliance should not come into contact or be covered with easily flammable materials, like curtains, textiles, walls and the like. Always ensure sufficient safety distance to flammable materials.
- DO NOT toast bread slices containing too much sugar with this appliance.
- DO NOT insert any metallic objects into the appliance when connected to a power supply.
- DO NOT immerse the appliance in water.
- DO NOT clean with jet/pressure washers.
- DO NOT leave the appliance unattended during operation.
- DO NOT obstruct or cover the appliance in any way when in use.
- Not suitable for outdoor use.
- Always switch off and disconnect the power supply to the appliance when not in use.
- This appliance must only be used in accordance with these instructions and by persons competent to do so.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.

- If the power cord is damaged, it must be replaced by an APURO agent or a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- APURO recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- This appliance is not intended to be used by laymen in household and similar applications such as:
  - Staff kitchen areas in shops, offices and other working environments;
  - Farm houses;
  - Hotels, motels and other residential type environments;
  - Bed and breakfast type environments.

## Product Description

**CU629-A** - APURO Double Slice Conveyor Toaster

## Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your APURO product.

## Pack Contents

The following is included:

- Apuro Conveyor Toaster
- Return chute
- Feeder rack
- Crumb tray
- Feet x 4
- Instruction manual

APURO prides itself on quality and service, ensuring that at the time of unpacking the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your APURO dealer immediately.

## Installation

**Note: The appliance shall not be installed where the public has access.**


- Place the unit on a heat-resistant surface. Avoid placing it on or close to flammable materials. Maintain a distance of 20cm between the appliance and walls or other objects for ventilation.
- Keep the unit away from splashing water and countertop's edge.

This appliance is intended to be used for commercial applications, for example in kitchens of restaurants, canteens, hospitals and in commercial enterprises such as bakeries, butcheries, etc., but not for continuous mass production of food.

**Note: Before using for the first time, clean the parts that will come into contact with food with warm soapy water. Let dry completely and ensure no water goes into the appliance inside.**

### Fit the feeder rack

1. Squeeze the arms of the feeder rack then slot into the mounting holes.
2. Rest the legs on the outside of the appliance.




### Fit the return chute

**Note: This toaster is designed to discharge the toast from the front of the appliance, using the return chute.**

Slide the return chute under the bottom of the appliance and secure its rear end to the two pins located on the side walls.

## Operation



## Toasting:

The appliance has 3 power levels:

<b>BREAD</b>	Full power to both upper and lower elements
<b>BUNS</b>	Full power to lower element only
<b>STBY</b>	Energy Saver (reduces power to minimum, providing quick heat up times when required)

The speed of the conveyor belt can also be altered to adjust the cooking level.

- Turn the belt speed knob anti-clockwise towards **LIGHT** (increases the speed of the belt) for a lighter toasting.
- Turn the belt speed knob clockwise towards **DARK** (slows the speed of the belt) for a darker toasting.

To toast:

1. Connect the appliance to the power supply.
2. Set the power level and belt speed.

**Note: Apuro recommend pre-heating the appliance for about 10-12 minutes before use.**

3. Place the bread on the Feeder rack.
4. The bread is toasted as it travels through the appliance.
5. If necessary, adjust the power level / belt speed to achieve the desired level of toasting.
6. **After use:** Turn the power level knob to "OFF" and disconnect from power supply.

## Cleaning, Care & Maintenance

- **Always turn Off the appliance and disconnect from the power supply before cleaning.**
- **Allow the appliance to cool before cleaning.**
- Rinse the return chute and wipe dry.
- Regularly remove and empty the crumb tray.
- Use warm, soapy water and a damp cloth to clean the exterior of the appliance.
- Dry thoroughly after cleaning.

## Troubleshooting

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
Appliance is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace Plug or lead
	Mains power supply fault	Check mains power supply
Appliance does not reach set temperature	Faulty power level knob	Consult a qualified technician
	Faulty element	Consult a qualified technician
Appliance heats up but indicator light does not come on	Indicator light has expired	Consult a qualified technician
HEAT indicator light comes on but appliance does not heat up	Faulty element	Consult a qualified technician
	Faulty power level knob	Consult a qualified technician
	Power level knob set incorrectly	Check power level knob setting
Appliance slow to heat up	Faulty element	Consult a qualified technician

Fault	Probable Cause	Solution
Belt does not move / is slower than usual	Loose chain	Consult a qualified technician
Uneven toasting	Incorrect power setting	Check power setting
	Not yet up to temperature	Allow appliance to heat up

## Technical Specifications

Note: Due to our continuous improvement process, the product specifications are subject to change without notice.

Model	Voltage	Power	Current	Dimensions H x W x D mm	Weight
CU629-A	220-240V~ 50/60Hz	2600W	11.3A	415 x 365 x 420	18.1kg

## Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

## Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

APURO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

APURO products have been approved to carry the following symbol:



**All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of BUFFALO. Every effort is made to ensure all details are correct at the time of going to press, however, BUFFALO reserves the right to change specifications without notice.**

# DECLARATION OF CONFORMITY

• Conformiteitsverklaring • Déclaration de conformité • Konformitätserklärung • Dichiarazione di conformità •  
• Declaración de conformidad • Declaração de conformidade

Equipment Type • Uitrustingstype • Type d'équipement • Gerätetyp • Tipo di apparecchiatura • Tipo de equipo	Model • Modèle • Modell • Modello • Modelo
Double slice conveyor toaster	CU629-A
Application of Territory Legislation & Council Directives(s) Toepassing van Europese Richtlijn(en) • Application de la/des directive(s) du Conseil • Anwendbare EU-Richtlinie(n) • Applicazione delle Direttive • Aplicación de la(s) directiva(s) del consejo	<b>Electrical Safety</b> IEC 60335-1:2020 IEC 60335-2-48:2021  <b>Electro-Magnetic Compatibility (EMC)</b> EN IEC 55014-1: 2021 EN IEC 55014-2: 2021 EN IEC 61000-3-2: 2019+A1: 2021 EN 61000-3-3: 2013+A1: 2019+A2: 2021
Manufacturer Name • Naam fabrikant • Nom du fabricant • Name des Herstellers • Nome del fabbricante • Nombre del fabricante	<b>Apuro</b>

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).

Ik, de ondergetekende, verklaar hierbij dat de hierboven gespecificeerde uitrusting goedgekeurd is volgens de bovenstaande Richtlijn(en) en Standaard(en).

Je soussigné, confirme la conformité de l'équipement cité dans la présente à la / aux Directive(s) et Norme(s) ci-dessus  
Ich, der/die Unterzeichnende, erkläre hiermit, dass das oben angegebene Gerät der/den oben angeführten Richtlinie(n) und Norm(en) entspricht.

Il sottoscritto dichiara che l'apparecchiatura di sopra specificata è conforme alle Direttive e agli Standard sopra riportati.

El abajo firmante declara por la presente que el equipo arriba especificado está en conformidad con la(s) directiva(s) y estándar(es) arriba mencionadas.

Date • Data • Date • Datum • Data  
• Fecha

Signature • Handtekening • Signature  
• Unterschrift Firma • Firma

Full Name • Volledige naam • Nom et prénom • Vollständiger Name •  
Nome completo • Nombre completo

Position • Functie • Fonction •  
Position • Qualifica • Posición

Manufacturer Address • Adres fabrikant • Adresse du fabricant •  
Adresse des Herstellers • Indirizzo del fabbricante • Dirección del fabricante

11<sup>th</sup> Dec 2024

DocuSigned by:

*Ashley Hooper*

B39382C9FD9C478...

**Ashley Hooper**

DocuSigned by:

*Brendan*

386FAD00DFE8483...

**Brendan Denmeade**

**Group Head of Product Quality & Compliance**

**Commercial Manager/ Responsible Supplier**

**Fourth Way,  
Avonmouth,  
Bristol,  
BS11 8TB  
United Kingdom**

**15 Badgally Road,  
Campbelltown  
NSW 2560**



**apuro**

CU629-A\_A5\_v1\_2024/12/23