

apuro

Heat and Hold Soup Kettle

Instruction manual



Caution: Read the instructions before using the appliance.

**Model:
HT759-A**

Safety Instructions

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - Fire Precautions
 - Wiring Regulations
 - Building Regulations
- **Caution! Hot surface!** 
- DO NOT immerse the appliance in water.
- DO NOT clean with jet/pressure washers.
- DO NOT move or carry the appliance when it is switched on and containing hot food.
- DO NOT operate the appliance without water in the outer container.
- Keep the lid closed when not serving.
- Always switch off and disconnect the power supply to the appliance when not in use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by an APURO agent or a recommended qualified technician in order to avoid a hazard.
- APURO recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Keep the appliance and its cord out of reach of Children aged less than 8 years.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your APURO product.

Intended for Wet Heat only!

Pack Contents

The following is included:

- APURO Soup Kettle
- Lid, metal collar
- Inner pot
- Instruction manual

APURO prides itself on quality and service, ensuring that at the time of unpacking the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your APURO dealer immediately.

Installation


Note: Do not install the appliance in an area where a water jet could be used.

Ensure the location for the unit can support its weight when full.

- Remove the appliance from the packaging. Make sure that all protective plastic film and plastic coatings are thoroughly removed from all surfaces.
- Before using for the first time, clean the inner pot with soapy water then dry well. For details, please refer to 'Cleaning, Care & Maintenance'.

Operation

Control panel



HEAT mode

Heat mode should be used when re-heating Soups and other foods from refrigerated or cold... This is to ensure the food is heated quickly and safely to serving temperature.

1. Press the heat mode button to start heating at full power. The heating mode indicator light will turn on and the display will show "H".
2. Press the heat mode button repeatedly to select the interval for stirring time alarm (off, 5 minutes, 10 minutes, 20 minutes). The selected time indicator light will turn on.
 - Tip: In general, the higher concentration of the soup, the shorter interval for stirring. (Like for mashed potato soup, 5-min interval for stirring is recommended.)
3. After pre-heating for about 20 minutes, pour the soup into the inner pot.
4. During heating, the appliance will give out 5 beeps at the set time interval to remind the user to stir the contents to avoid burning.
5. When the soup is heated, press the hold mode button to manually switch from heating mode to hold mode (Keeping warm mode). Or, the appliance will keep working at full power thus consume extra electricity.

Note: When the appliance is on under heating mode for 2 hours, it will automatically switch from heating mode to hold mode.

Attention: Never move or carry the appliance when it is switched on or contains hot liquid.

Getting started

1. Fill the outer pot with approximately 3.5L water. Do not exceed the **MAX** marking.
2. Attach the metal collar, then carefully place the inner pot into the appliance. Fit the lid.

Note: The inner pot must NOT float, even when empty. If the pot floats, reduce the amount of water in the outer pot.

3. Connect the appliance to the mains power supply and turn on the power switch ("I" position).
4. The display will show "—", indicating the appliance has entered Standby.

HOLD mode

Hold mode should be used to hold already hot food at optimum serving temperatures. The desired power/temperature can be set according to preference and type of food.

1. Press the hold mode button to enter the hold mode. The indicator light will turn on.

2. Press the power control buttons $\oplus$ and $\ominus$ to set the temperature level:

Level on display	Temperature (°C)
1	50-55
2	55-60
3	60-65
4	65-70
5	70-75
6	75-80
7	80-85
8	85-90
9	>90

3. After about 5 minutes, the appliance starts to keep the soup at the set temperature level.
 4. After use, turn off the power switch ("O" position) and unplug the appliance.

- The inner container and lid are dishwasher safe.
- Dry thoroughly after cleaning.

Descaling

In hard water areas lime scale can build up within the appliance after prolonged use. To descale the appliance.

1. Remove the lid and inner pot first.
2. Pour a solution of de-scaler and water into the outer pot.
3. Follow the manufacturer's instructions on the de-scale solution with reference to the length of time required to soak, agitation, water temperature and on how to dispose of the solution safely.
4. Fill the outer pot with clean water and turn the appliance On to flush out the system. Flush out the system thoroughly to remove any de-scaler residue.
5. The appliance is now ready for use.

Note: Use a suitable descaler and always follow the manufacturer's instructions. APURO recommend that this appliance is descaled every 3 months or more frequently in hard water areas.

IMPORTANT: Failure to descale or maintain will invalidate your guarantee.

Cleaning, Care & Maintenance

- **Always turn off and disconnect the appliance from the power supply before cleaning.**
- Clean any spilt food on the appliance immediately.
- Use soapy water and a damp cloth to clean the exterior of the appliance.

Troubleshooting

A qualified technician should carry out repairs if required.

Fault	Probable Cause	Solution
The unit is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug and lead are damaged	Replace plug or lead
	Mains power supply fault	Check mains power supply
	Auto re-set activated	Allow product to cool for 30 minutes
Display issue	Problem with the temperature fuse or PCB components	Consult a qualified technician for checking and replacement
Indicator light not On	Problem with PCB components	Consult a qualified technician for replacement
Soup not heating up	Wrong working mode selected	Select the heating mode
Soup not warm	Insufficient temperature setting	Increase temperature setting

Technical Specifications

Note: Due to our continuous improvement process, the product specifications are subject to change without notice.

Model	Voltage	Power	Current	Capacity	Weight	Dimensions H x W x D mm
HT759-A	220-240V~ 50-60Hz	1400W	6.09A	9L	5.78kg	405 x 303 x 312

Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

APURO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

APURO products have been approved to carry the following symbol:



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Apuro.
Every effort is made to ensure all details are correct at the time of going to press, however, Apuro reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

- Conformiteitsverklaring • Déclaration de conformité • Konformitätserklärung • Dichiarazione di conformità •
• Declaración de conformidad • Declaração de conformidade

Equipment Type • Uitrustingstype • Type d'équipement • Gerätetyp • Tipo di apparecchiatura • Tipo de equipo		Model • Modèle • Modell • Modello • Modelo
Heat and hold soup kettle		HT759-A
Application of Territory Legislation & Council Directives(s) Toepassing van Europese Richtlijn(en) • Application de la/des directive(s) du Conseil • Anwendbare EU-Richtlinie(n) • Applicazione delle Direttive • Aplicación de la(s) directiva(s) del consejo	Electrical Safety AS/NZS 60335-1:2020 AS/NZS 60335-2-15:2019 Electro-Magnetic Compatibility (EMC) EN IEC 55014-1:2021 EN IEC 55014-2:2021 EN IEC 61000-3-2: 2019+A1: 2021 EN 61000-3-3: 2013+A1: 2019+A2: 2021	
Manufacturer Name • Naam fabrikant • Nom du fabricant • Name des Herstellers • Nome del fabbricante • Nombre del fabricante		Apuro

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).

Ik, de ondergetekende, verklaar hierbij dat de hierboven gespecificeerde uitrusting goedgekeurd is volgens de bovenstaande Richtlijn(en) en Standaard(en).

Je soussigné, confirme la conformité de l'équipement cité dans la présente à la / aux Directive(s) et Norme(s) ci-dessus

Ich, der/die Unterzeichnende, erkläre hiermit, dass das oben angegebene Gerät der/den oben angeführten Richtlinie(n) und Norm(en) entspricht.

Il sottoscritto dichiara che l'apparecchiatura di sopra specificata è conforme alle Direttive e agli Standard sopra riportati.

El abajo firmante declara por la presente que el equipo arriba especificado está en conformidad con la(s) directiva(s) y estándar(es) arriba mencionadas.

Date • Data • Date • Datum •
Data • Fecha

Signature • Handtekening •
Signature • Unterschrift Firma •
Firma

Full Name • Volledige naam • Nom
et prénom • Vollständiger Name •
Nome completo • Nombre completo

Position • Functie • Fonction •
Position • Qualifica • Posición

Manufacturer Address • Adres
fabrikant • Adresse du fabricant •
Adresse des Herstellers • Indirizzo del
fabbricante • Dirección del fabricante

27th Nov 2025

Signed by:

Ashley Hooper
AB6DB7656FFB441...

Ashley Hooper

Group Head of Product Quality & Compliance

15 Badgally Road, Campbelltown NSW 2560



apuro

HT759-A_A5_v1_2025/11/27