

HOST

Stainless Steel Prep Station

Instruction manual

Model:

HOST0110PSM
HOST0111PSL



**Read this instruction
manual carefully
before use**

	(i) x 1		(vi) x 1
	(ii) x 2		(vii) x 4
	(iii) x 1		(viii) x 4
	(iv) x 2		(ix) x 1
	(v) x 16		(x) x 1

A



B



C



D



E



F



G



Safety Instructions

- Whilst all care has been taken to remove sharp edges, care must be taken when cleaning or handling the prep station to prevent risk of injury from exposed metal edges.
- Do not overload the work top or shelves causing them to bend.

Assembly

Note: Be sure to check all packaging materials for any small parts that may have come loose during transportation

1. Remove all protective film, taking care to avoid scratching the surfaces.
2. Place the lower shelf **(i)** on its side on the floor **[A]**. The lower shelf has leg slots on the outside of each corner.
3. Insert the rear legs (the two longest) **(ii)** into the lower shelf, lining up the socket with the lines marked on the leg.
4. Slide the work top **(iii)** on to the two legs, lining up the sockets with the lines marked on the leg **[B]**.
5. Insert the two shorter legs **(iv)** through the front sockets of the lower shelf and in to the work top sockets.
6. Use grub screws **(v)** to loosely fix the lower shelf and work top to the legs with the allen key **(vi)**, then stand upright **[C, D, E]**. Tighten the screws when all shelves are correctly located.
7. Roll a rubber gasket **(vii)** followed by a collar **(viii)** over each of the rear legs and down to the work top.
8. Lower the gastronorm shelf **(ix)** over the rear legs **[F]**. Secure the support sockets (attached to the shelf) in place with grub screws **(v)** and tighten.
9. Roll a rubber gasket followed by a collar over each of the rear legs and down to the gastronorm shelf.
10. Place the upper shelf **(x)** over the four legs and secure in place with the remaining grub screws **[G]**.
11. Insert the gastronorm pans **(NOT INCLUDED)** in to the gastronorm shelf.

Note: The Prep Station will accommodate 1/3, 1/6 and 1/9 size gastronorm pans. Adjust the feet if necessary to level the prep station

Before using for the first time HOST recommend all surfaces are cleaned thoroughly with a suitable cleaning agent. Remove all cleaning residues and dry thoroughly.

Cleaning

- Clean regularly using a cleaning agent suitable for use with stainless steel.
- Always remove cleaning agent residue. This can discolour the surfaces.
- Never leave the surface damp as this can cause discolouration.

Service

Should your appliance have a fault, please visit the Service section of the HOST website.

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of HOST.
Every effort is made to ensure all details are correct at the time of going to press, however, HOST reserve the right to change specifications without notice.



www.host-appliances.com

HOST0110PSM_HOST0111PSL_EN_A5_v1_2022/09/01