

HOST

Convection oven Instruction manual

Model:

HOST0924CO
HOST0925CO



Read this instruction
manual carefully
before use

Safety Instructions

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - BS EN Codes of Practice
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations




- **Caution! Hot surface!**
The temperature of accessible surfaces maybe high when the appliance is operating. Always wear oven mittens when removing food.
- DO NOT immerse the appliance in water.
- DO NOT clean with a water jet or a steam cleaner.
- DO NOT move or carry the appliance when it is switched on.
- DO NOT leave the appliance unattended during operation.
- DO NOT obstruct or cover the appliance in any way when in use.
- During and after cooking, the unit is still hot. Never touch the surface to avoid scalding.
- Always switch off and disconnect the power supply to the appliance when not in use.
- This appliance must only be used in accordance with these instructions and by persons competent to do so.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a recommended qualified technician in order to avoid a hazard.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- HOST recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- HOST recommend that this product is connected to a circuit protected by an appropriate RCD (Residual Current Device).

Installation

- Place the unit on a heat-resistant surface. Avoid placing it on or close to flammable materials. Maintain a distance of 20cm (7 inches) between the appliance and walls or other objects for ventilation.
- Keep the unit away from splashing water and countertop's edge.

Operation



Before using for the first time

Note:

This appliance is intended to be used for commercial applications, for example in kitchens of restaurants, canteens, hospitals and in commercial enterprises such as bakeries, butcheries, etc., but not for continuous mass production of food.

1. Wash the appliance thoroughly (See section "Cleaning, Care & Maintenance").
2. Place the baking accessories (not supplied) inside the oven.
3. Close the door.
4. Set the Timer knob to 30 minutes and the thermostat knob to MAX setting (250°C) to burn off any manufacturing residues.

Note:

- **If the desired time is under 20 minutes, turn the Timer knob beyond 20 first, then turn back to the required setting.**
- **The Timer knob also acts as the Power switch. When it is set to "OFF", the appliance will switch off automatically.**
- **When the timer knob is set to "Stay on", the appliance will keep working continuously.**

5. When the set time elapses, the timer knob will go back to "OFF" to switch the appliance off.
6. Disconnect the appliance from the power supply and allow it to cool down.

Start cooking

1. Connect the appliance to the mains power supply.
2. Set the Timer knob to the desired time (0-120 minutes). The power indicator light will come on and the fan will start to run.
3. Set the thermostat knob to the desired temperature (50°C-250°C). The heating indicator light will come on and the appliance will start to heat up.
4. When the set temperature is reached, the heating indicator light will turn off.

Note:

- **During use, the heating indicator light will cycle on/off, indicating the set temperature is being maintained.**
- **During cooking, the temperature and cooking time can be adjusted at any time.**

5. When the cooking time elapses, the appliance will beep then turn Off.

Automatic overheating protection

- This appliance is featured with an overheating protection. Should the temperature exceed safe levels the appliance will automatically cut off power.
- Allow appliance to cool at least 30 minutes.
- The appliance is now reset and can be used as normal.

Cleaning, Care & Maintenance

- **Warning: Always turn off and disconnect the appliance from the power supply before cleaning. Always allow the appliance to cool before cleaning.**
- Clean the interior of the appliance as often as possible.
- Do not use abrasive cleaning agents. These can leave harmful residues.
- For stains on the interior walls, wipe with a cloth dampened with some mild soapy solution. Ensure no moisture enters the inside of the cabinet.
- Always wipe dry after cleaning.

Cleaning all baking accessories (not supplied)

- After use, remove the parts from the appliance for cleaning.
- Clean using warm, soapy water. Rinse thoroughly and dry well.
- Re-locate into the appliance.

Troubleshooting

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace plug or lead
	Fuse in the plug has blown	Replace the fuse
	Mains power supply fault	Check mains power supply
Unit heats up but indicator light does not come on	Bulb has expired	Consult a qualified technician
Appliance does not heat up	Faulty heating elements	Consult a qualified technician
	Faulty control knobs	Consult a qualified technician
	Thermostat set incorrectly	Check and adjust the setting
Appliance slow to heat up	Faulty heating elements	Consult a qualified technician
	Interior surfaces not clean	Clean the surfaces
Food overcooked or scorched	Temperature setting too high	Select a lower temperature
	Faulty thermostat	Consult a qualified technician
Appliance stopped suddenly	Automatic overheating protection is activated	Allow appliance to cool at least 30 minutes

Service

Should your appliance have a fault, please visit the Service section of the HOST website:

<https://www.host-appliances.com/repairs>

Technical Specifications

Model	Voltage	Power	Temperature range	Timer range	Capacity	Dimensions (H x W x D) (mm)	Weight
HOST0924CO	220-240V~ 50Hz-60Hz	2500W	50°C - 250°C	1-120 minutes	4 x GN 2/3	502 x 495 x 600	20kg
HOST0925CO		2900W	50°C - 250°C		4 x GN 1/1	502 x 675 x 600	29kg

Due to our continuing program of research and development, the specifications herein are subject to change without notice.

Electrical Wiring

The appliance is supplied with a 3 pin BS1363 plug and lead.

The plug is to be connected to a suitable mains socket.

The appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



HOST parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of HOST.
Every effort is made to ensure all details are correct at the time of going to press, however, HOST reserve the right to change specifications without notice.

HOST UKCA Declaration of Conformity



We {Host} of {Host House, Newhouse Farm Industrial Estate, Mathern, Chepstow, NP16 6UP} hereby declare that the equipment is in conformity with the requirements of the following Regulations:

- Electrical Equipment (Safety) Regulations 2016
- Electromagnetic Compatibility Regulations 2016
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

We hereby declare that:

Equipment Model number:

HOST0924CO
HOST0925CO

Commercial Convection Oven 4 x GN 2/3
Commercial Convection Oven 4 x GN 1/1

is in conformity with the applicable requirements of the following documents:

Ref. No.	Edition/date
BS EN 60335-1	2012 +A11:2014 +A13:2017 +A1:2019 +A14:2019 +A2:2019
BS EN 60335-2-42	2003 +A1:2008 +A11:2012
BS EN 62233	2008
BS EN IEC 55014-1	2021
BS EN IEC 55014-2	2021
BS EN IEC 61000-3-2	2019 +A1:2021
BS EN 61000-3-3	2013 +A1:2019 +A2:2021

I hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications and is in accordance with the requirements of the Regulations:

Signed by:

DocuSigned by:

866FAAB7CD48499...

Full Name: Jess Attree
Title: General Manager
Location: Chepstow, Great Britain
Date: 10TH August 2023



www.host-appliances.com

HOST0924CO_HOST0925CO_EN_A5_v1_2023/09/14