

# HOST

## Refrigerators/Freezers

Instruction manual

### Model:

HOST1018CR / HOST1019CF  
HOST1020UR / HOST1021UF  
HOST1022UR / HOST1023UF  
HOST1024CR / HOST1025CF  
HOST1026UR / HOST1027UF  
HOST1028UR / HOST1029UF



Read this instruction  
manual carefully  
before use

---

## Safety Instructions

---

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
  - Health and Safety at Work Legislation
  - BS EN Codes of Practice
  - Fire Precautions
  - IEE Wiring Regulations
  - Building Regulations
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT use the appliance outside.
- DO NOT use this appliance to store medical supplies.
- DO NOT allow oil or fat to come into contact with the plastic components or door seal. Clean immediately if contact occurs.
- DO NOT store products on top of the appliance.
- Bottles that contain a high percentage of alcohol must be sealed and placed vertically in the refrigerator.
- Always carry, store and handle the appliance in a vertical position and move by holding the base of the appliance.
- Always switch off and disconnect the power supply to the unit before cleaning.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.
- HOST recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- HOST recommend that this product is connected to a circuit protected by an appropriate RCD (Residual Current Device).

### Caution: Risk of Fire



- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

**Warning: Keep all ventilation openings clear of obstruction. Unit should not be boxed in without adequate ventilation.**

- **Warning:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **Warning:** Do not damage the refrigerant circuit.
- **Warning:** Do not use electrical appliances inside the food storage compartments of the appliance.

---

## Installation

---

**Note:** A bracket is used to support the door during transportation. On receipt please remove the bracket.

**Note:**

**Not for use in vans or trailers, food trucks or similar vehicles.**

**If the unit has not been stored or moved in an upright position, let it stand upright for approximately 12 hours before operation. If in doubt allow to stand.**


1. Remove the appliance from the packaging. Make sure that all protective plastic film and coatings are thoroughly removed from all surfaces.
2. To optimize performance and longevity, ensure a minimum clearance of 2.5cm is maintained between the unit and walls and other objects, with a minimum 20cm clearance on the top. **NEVER LOCATE NEXT TO A HEAT SOURCE.**

**Note:**

**Before using the appliance for the first time, clean the shelves and interior with soapy water. The appliance is supplied with feet by default. However, castors can be supplied as an option.**

## Operation

**Control panel:** The control panel is located on the front of the appliance.



### Turn On

1. Close the door of the appliance.
2. Connect the appliance to a mains power supply.
3. The appliance will automatically turn on.

### To set the operating temperature

1. Press and release the key. The indicator and the display will light up. You can now view and modify the cabinet temperature.
2. Press the or keys to set the required temperature.
3. Press the key to store the temperature and exit the temperature viewing/modifying mode.

**Note:**

**The controller has been pre-set optimally by the manufacturer so we do not recommend customer adjustments at will. Best cooling/freezing performance can be achieved so long as the unit is optimally filled and the internal circulation is not obstructed.**

### Manual Defrost

Press and hold + keys for 3 seconds to switch between cooling, defrost/defrost delay and dripping.

Indicator	Meaning	
	On	Defrost runs
	Flash	Start defrost dripping
	Off	Defrost stops

### Storing Food

To get the best results from your HOST appliance, follow these instructions:

- Only store foodstuffs in the appliance when it has reached the correct operating temperature.
- Do not place uncovered items as below inside the appliance, as this can lead to a damaged and leaking evaporator, and thus void your warranty: hot food, hot liquids, acidic fluids, acidic products.
- Wrap or cover food where possible.
- Do not obstruct the fans inside the appliance.
- Avoid opening the doors for prolonged periods of time.

### Lock/Unlock the Door

- A lock is fitted to the doors to ensure foodstuffs are kept secure within your HOST appliance.
- Use the keys provided to lock/unlock the door.

## Cleaning, Care & Maintenance

- **Switch off and disconnect from the power supply before cleaning.**
- Clean the interior of the appliance as often as possible.
- Do not use abrasive cleaning agents. These can leave harmful residues.
- Clean the door seal with warm soapy water.
- Always wipe dry after cleaning.
- Do not allow water used in cleaning to run through the drain hole into the evaporation pan.
- Take care when cleaning the rear of the appliance. Sharp edges can cut.

Condensation and ice will form with frequent and prolonged opening of the doors. Operating outside of the recommend temperature range and placing next to a heat source will also increase the amount of ice and internal/external condensation. If external condensation occurs wipe the surface down with a cloth. Excessive ice will result in longer running times that will increase energy consumption and increase the deterioration of components.

## Cleaning the Condenser

Periodically cleaning the condenser can extend the life of the appliance. HOST recommend that a qualified technician should clean the condenser.

---

## Troubleshooting

---

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace plug or lead
	Fuse in the plug has blown	Replace the fuse
	Mains power supply fault	Check mains power supply
The appliance turns on, but the temperature is too high/low	Too much ice on the evaporator	Defrost the appliance
	Condenser blocked with dust	Clean the condenser
	Doors are not shut properly	Check doors are shut and seals are not damaged
	Appliance is located near a heat source or air flow to the condenser is being interrupted	Move the refrigerator to a more suitable location
	Ambient temperature is too high	Increase ventilation or move appliance to a cooler position
	Unsuitable foodstuffs are being stored in the appliance	Remove any excessive hot foodstuffs or blockages to the fan
The appliance is leaking water	Appliance is overloaded	Reduce the amount of food stored in the appliance
	The appliance is not properly levelled	Adjust the screw feet to level the appliance (if applicable)
The appliance is leaking water	The discharge outlet is blocked	Clear the discharge outlet
	Movement of water to the drain is obstructed	Clear the floor of the appliance (if applicable)
The appliance is leaking water	The water container is damaged	Consult a qualified technician
	The drip tray is overflowing	Empty the drip tray (if applicable)
The appliance is unusually loud	Loose nut/screw	Check and tighten all nuts and screws
	The appliance has not been installed in a level or stable position	Check installation position and change if necessary
The display lamp does not light	Lamp needing replacing	Consult a qualified technician

---

## Service

---

Should your appliance have a fault, please visit the Service section of the HOST website:

<https://www.host-appliances.com/repairs>

## Technical Specifications

Note: Due to our continuing program of research and development, the specifications herein may be subject to change without notice.

Model	Voltage	Power	Current	Temperature Range	Capacity (L)	Net usable capacity (L)	Refrigerant	Dimensions H x W x D mm	Weight (kg)
HOST1018CR HOST1024CR	220-240V~	100W	0.7A	2°C to 8°C	150	69	R600a	825 x 600 x 583	44
HOST1019CF HOST1025CF		105W	0.8A	-10°C to -25°C	140	78	R600a	825 x 600 x 583	44.5
HOST1020UR HOST1026UR		130W	0.8A	2°C to 8°C	400	239	R600a	1870 x 600 x 583	69
HOST1021UF HOST1027UF		150W	0.9A	-10°C to -25°C	365	254	R600a	1870 x 600 x 583	71
HOST1022UR HOST1028UR		130W	0.9A	2°C to 8°C	600	441	R600a	1910 x 777 x 693	90
HOST1023UF HOST1029UF		300W	1.4A	-10°C to -25°C	600	465	R600a	1910 x 777 x 693	94

Note: For optimal product performance and efficiency, please ensure to mind the net usable capacity (load limit) when filling.

## Electrical Wiring

The appliance is supplied with a 3 pin BS1363 plug and lead.  
The plug is to be connected to a suitable mains socket.  
The appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.

If in doubt consult a qualified electrician.



Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

## Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



HOST parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of HOST.  
Every effort is made to ensure all details are correct at the time of going to press, however, HOST reserve the right to change specifications without notice.

# HOST UKCA Declaration of Conformity



We {Host} of {Host House, Newhouse Farm Industrial Estate, Mathern, Chepstow, NP16 6UP} hereby declare that the equipment is in conformity with the requirements of the following Regulations:

- Supply of Machinery (Safety) Regulations 2008
- Electromagnetic Compatibility Regulations 2016
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012
- Ecodesign for Energy-related Products Regulations 2010 (as amended)

We hereby declare that:  
Equipment Model number:


HOST1018CR	150ltr Under Counter Stainless Steel Fridge
HOST1019CF	140ltr Under Counter Stainless Steel Freezer
HOST1020UR	400ltr Upright Stainless Steel Fridge
HOST1021UF	365ltr Upright Stainless Steel Freezer
HOST1022UR	600ltr Upright Stainless Steel Fridge
HOST1023UF	600ltr Upright Stainless Steel Freezer
HOST1024CR	150ltr Under Counter White Fridge
HOST1025CF	140ltr Under Counter White Freezer
HOST1026UR	400ltr Upright White Fridge
HOST1027UF	365ltr Upright White Freezer
HOST1028UR	600ltr Upright White Fridge
HOST1029UF	600ltr Upright White Freezer

is in conformity with the applicable requirements of the following documents:

Ref. No.	Edition/date
BS EN 60335-1	2012 +A11:2014 +A13:2017 +A1:2019 +A14:2019 +A2:2019
BS EN 60335-2-89	2010 +A1:2016 +A2:2017
BS EN 62233	2008
BS EN IEC 55014-1	2021
BS EN IEC 55014-2	2021
BS EN IEC 61000-3-2	2019 +A1:2021
BS EN 61000-3-3	2013 +A1:2019 +A2:2021

I hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications and is in accordance with the requirements of the Regulations:

Signed by:

DocuSigned by:  
  
866FAAB7CD48499...

Full Name: Jess Attree  
Title: General Manager  
Location: Chepstow, Great Britain  
Date: 29<sup>th</sup> August 2023



[www.host-appliances.com](http://www.host-appliances.com)

HOST1018CR to HOST1029UF\_EN\_A5\_v1\_2023/08/31