

# HOST

## Hotel Room Refrigerator

Instruction manual

**Model:**

HOST1205HR



Read this instruction  
manual carefully  
before use

---

## **Safety Instructions**

---

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
  - Health and Safety at Work Legislation
  - BS EN Codes of Practice
  - Fire Precautions
  - IEE Wiring Regulations
  - Building Regulations
- DO NOT immerse in water, or use steam/jet washers to clean the unit.
- This appliance is intended to be used in household and similar applications.
- DO NOT allow oil or fat to come into contact with the plastic components or door seal. Clean immediately if contact occurs.
- DO NOT store products on top of the appliance.
- HOST Hotel Refrigerators are designed for drink chilling and storage and are not recommended for the storing of foodstuffs.
- Bottles that contain a high percentage of alcohol must be sealed and placed vertically in the refrigerator.
- Always carry, store and handle the appliance in a vertical position and move by holding the base of the appliance.
- Always switch off and disconnect the power supply to the unit before cleaning.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a recommended qualified technician in order to avoid a hazard.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- HOST recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- HOST recommend that this product is connected to a circuit protected by an appropriate RCD (Residual Current Device).

### Caution: Risk of Fire



- Do not store explosive substances such as aerosol cans with a flammable propellant in this

appliance.

**Warning: Keep all ventilation openings clear of obstruction. Unit should not be boxed in without adequate ventilation.**

- **Warning:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **Warning:** Do not damage the refrigerant circuit.
- **Warning:** Do not use electrical appliances inside the food storage compartments of the appliance.

---

## Installation

---

### Note:

**Not for use in vans or trailers, food trucks or similar vehicles.**

**If the unit has not been stored or moved in an upright position, let it stand upright for approximately 12 hours before operation. If in doubt allow to stand.**

1. Remove the appliance from the packaging. Make sure that all protective plastic film and coatings are thoroughly removed from all surfaces.
2. To optimize performance and longevity, ensure a minimum clearance of 2.5cm is maintained between the unit and walls and other objects, with a minimum 20cm clearance on the top.  
**NEVER LOCATE NEXT TO A HEAT SOURCE.**


**Note:** Before using the appliance for the first time, clean the shelves and interior with soapy water.

**WARNING:** When positioning the appliance, ensure the supply cord is not trapped or damaged.


**WARNING:** Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

## Reverse the Door

1. Disconnect the appliance from the power supply.
2. The door is opened from left side originally.
3. Remove the 2 screw covers and screws on the right top and keep for later use. Then remove the door and right hinge.



4. Remove the screw covers and screws on the left top. Then pull out the locking plate.




5. Insert the left hinge (supplied) and secure with the 2 screws. Then attach screw covers.
6. Remove the bottom spindle from the right foot and fix it on the left foot.
7. Install the door correctly.
8. Fix the previously removed locking plate to the right top with screws. Then attach screw covers.
9. Now the door is opened from right side.

## Operation

### Controller

The controller is located inside the cabinet. The thermostat is graded from **High** (warm) to **Low** (cold).



### Turn On

1. Set the thermostat to the desired setting.
2. Close the door of the appliance.
3. Connect the appliance to a mains power supply.

### Lock/Unlock the Door

Use the keys provided to lock/unlock the door.

**To avoid contamination of drink, please respect the following instructions:**

- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- If the refrigerating appliance is left empty for long periods, switch it off. Then defrost and clean it thoroughly. Let it dry well and leave the door open to prevent mould developing within the appliance.
- Clean regularly surfaces that can come in contact with drink and accessible drainage systems.

### Refrigerating tips:

- Condensation and ice will form with frequent and prolonged opening of the doors.
- Operating outside of the recommend temperature range and placing next to a heat source will also increase the amount of ice and internal/external condensation. If external condensation occurs wipe the surface down with a cloth.
- Excessive ice will result in longer running times that will increase energy consumption and increase the deterioration of components.
- If the gasket or seal is damaged or deformed, energy consumption will increase. To restore efficiency, replace gasket.

## Cleaning, Care & Maintenance

- **Switch off and disconnect from the power supply before cleaning.**
- Clean the interior of the appliance as often as possible.

- Do not use abrasive cleaning agents. These can leave harmful residues.
- Clean the door seal with water only.
- Always wipe dry after cleaning.
- If left unused for any length of time, store the appliance with the door ajar.

## Defrost

In case of Ice built-up (3-5mm thick), empty the unit and disconnect from power supply. Leave the door open and manually defrost the appliance. Never use sharp objects for scraping.

## Troubleshooting

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace plug or lead
	Fuse in the plug has blown	Replace the fuse
	Mains power supply fault	Check mains power supply
Unit cabinet is not cold enough	Temperature set incorrectly	Check temperature and reset if necessary
	External environment may require colder temperature	Check temperature and reset if necessary
	The door is opened too often	Only open when necessary
	Door seal is worn	Consult a qualified technician
Door will not close properly	Appliance is not level	Check installation position and change if necessary
	Door has been reversed and not properly fitted	See "Reversing the Door"
	Shelves are out of position	Check shelves are properly inserted
	Door seal is dirty	Wipe clean with a damp cloth
The appliance is noisy	Loose nut/screw	Check and tighten all nuts and screws
	Appliance has not been installed in a level or stable position	Check installation position and change if necessary

## Service

Should your appliance have a fault, please visit the Service section of the HOST website.

## Technical Specifications

Due to our continuing program of research and development, the specifications herein are subject to change without notice.

Model	Voltage	Power	Current	Temperature Range	Capacity (Litre)	Refrigerant	Dimensions (H x W x D) (mm)	Weight (kg)
HOST1205HR	220-240V~50/60Hz	60W	0.3A	3°C - 12°C	29	R600a 25g	530 x 400 x 430	12.3

**Climate Class: N**

**Design type: Free standing**

**Note:** For optimal product performance and efficiency, please ensure to mind the net usable capacity (load limit) when filling.

**Impact of temperature settings on food waste:**

In order to reduce food waste from decomposition or dehydration, this appliance should be operated in its designated operating range.

Optimum temperature for food storage: 12°C

**Optimum ambient temperature and humidity:**

This appliance is intended to be used at ambient temperatures ranging from 16°C to 32°C.

This appliance is intended to operate in climate where the maximum humidity is 75%.

**To order spare parts, please visit the link below then type the relative item code and Spares:**

[www.host-appliances.com](http://www.host-appliances.com)

**Minimum period of spares parts to be available:**

Door handles, door hinges, trays and baskets will be made available for a minimum of seven years after the last unit of the model is placed on the market. A further selection of technical spares will also be available to Professional users for a minimum of seven years. Door gaskets will be made available for a minimum of 10 years.

**Model information can be found on the product:**

The Model Identifier can usually be found on the inside wall and on the reverse of the unit.

## Electrical Wiring

The appliance is supplied with a 3 pin BS1363 plug and lead.

The plug is to be connected to a suitable mains socket.

The appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E



This appliance must be earthed.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

## Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



HOST parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of HOST.

Every effort is made to ensure all details are correct at the time of going to press, however, HOST reserve the right to change specifications without notice.

# HOST UKCA Declaration of Conformity



We {Host} of {Host House, Newhouse Farm Industrial Estate, Mathem, Chepstow, NP16 6UP} hereby declare that the equipment is in conformity with the requirements of the following Regulations:

- Electrical Equipment (Safety) Regulations 2016
- Electromagnetic Compatibility Regulations 2016
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012
- Ecodesign for Energy-related Products Regulations 2010 (as amended)

We hereby declare that:


Equipment Model number      HOST1205HR      Hotel Room Refrigerator - 29Ltr

is in conformity with the applicable requirements of the following documents

Ref. No.	Edition/date
BS EN 60335-1	2012 +A11:2014 +A13:2017 +A1:2019 +A14:2019 +A2:2019
BS EN 60335-2-24	2010 +A1:2019 +A2:2019
BS EN 62233	2008
BS EN 55014-1	2017
BS EN 55014-2	2015
BS EN IEC 61000-3-2	2019
BS EN 61000-3-3	2013 +A1:2019

I hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications and is in accordance with the requirements of the Regulations:

Signed by:

DocuSigned by:  


Full Name **Jess Attree**  
Title: **General Manager**  
Location: Chepstow, Great Britain  
Date: **9<sup>th</sup> August 2022**



[www.host-appliances.com](http://www.host-appliances.com)

HOST1205HR\_EN\_A5\_v2\_2023/01/16